

# Grandstream Networks, Inc.

---

HT812/HT814

Analog Telephone Adaptors

## **Administration Guide**



## **COPYRIGHT**

©2022 Grandstream Networks, Inc. <https://www.grandstream.com>

All rights reserved. Information in this document is subject to change without notice. Reproduction or transmittal of the entire or any part, in any form or by any means, electronic or print, for any purpose without the express written permission of Grandstream Networks, Inc. is not permitted.

The latest electronic version of this user manual is available for download here:

<https://www.grandstream.com/support>

Grandstream is a registered trademark and Grandstream logo is trademark of Grandstream Networks, Inc. in the United States, Europe, and other countries.

## **CAUTION**

Changes or modifications to this product not expressly approved by Grandstream, or operation of this product in any way other than as detailed by this User Manual, could void your manufacturer warranty.

## **WARNING**

Please do not use a different power adaptor with your devices as it may cause damage to the products and void the manufacturer warranty.



## GNU GPL INFORMATION

The firmware for the HT812/HT814 contains third-party software licensed under the GNU General Public License (GPL). Grandstream uses software under the specific terms of the GPL. Please see the GNU General Public License (GPL) for the exact terms and conditions of the license.

Grandstream GNU GPL related source code can be downloaded from Grandstream web site from:

<https://www.grandstream.com/support/faq/gnu-general-public-license/gnu-gpl-information-download>



## Table of Content

<b>DOCUMENT PURPOSE .....</b>	<b>7</b>
<b>CHANGE LOG .....</b>	<b>8</b>
Firmware Version 1.0.35.4 .....	8
Firmware Version 1.0.33.4 .....	8
Firmware Version 1.0.31.1 .....	8
Firmware Version 1.0.29.8 .....	8
Firmware Version 1.0.27.2 .....	8
Firmware Version 1.0.25.5 .....	8
Firmware Version 1.0.23.5 .....	8
Firmware Version 1.0.21.4 .....	9
Firmware Version 1.0.19.11 .....	9
Firmware Version 1.0.17.5 .....	9
Firmware Version 1.0.15.4 .....	9
Firmware Version 1.0.13.7 .....	10
Firmware Version 1.0.11.6 .....	10
Firmware Version 1.0.10.6 .....	10
Firmware Version 1.0.9.3 .....	11
Firmware Version 1.0.8.7 .....	11
Firmware Version 1.0.5.11 .....	11
Firmware Version 1.0.3.7 .....	12
Firmware Version 1.0.3.2 .....	12
Firmware Version 1.0.2.7 .....	12
Firmware Version 1.0.2.5 .....	12
Firmware Version 1.0.2.3 .....	12
Firmware Version 1.0.2.1 .....	13
<b>WELCOME .....</b>	<b>14</b>



<b>PRODUCT OVERVIEW .....</b>	<b>15</b>
Feature Highlights .....	15
HT812/HT814 Technical Specifications .....	16
<b>GETTING STARTED.....</b>	<b>18</b>
Equipment Packaging .....	18
HT812/HT814 Ports Description.....	19
Connecting HT812/HT814 .....	19
<i>Scenario 1: Connecting the HT812/HT814 using WAN Port.....</i>	<i>19</i>
<i>Scenario 2: Connecting the HT812/HT814 using LAN Port .....</i>	<i>20</i>
HT812/HT814 LEDs Pattern .....	20
<b>CONFIGURATION GUIDE.....</b>	<b>22</b>
Obtain HT812/HT814 IP Address via Connected Analogue Phone.....	22
Understanding HT812/HT814 Interactive Voice Prompt Response Menu .....	22
Configuration via Web Browser .....	24
<i>Accessing the Web UI .....</i>	<i>25</i>
<i>Web UI Access Level Management.....</i>	<i>26</i>
<i>Saving the Configuration Changes.....</i>	<i>26</i>
<i>Changing Admin Level Password.....</i>	<i>26</i>
<i>Changing User Level Password .....</i>	<i>26</i>
<i>Changing Viewer Password.....</i>	<i>27</i>
<i>Changing HTTP Web Port.....</i>	<i>27</i>
Web Configuration Pages Definitions .....	28
<i>Status Page Definitions .....</i>	<i>28</i>
<i>Basic Settings Page Definitions.....</i>	<i>30</i>
<i>Advanced Settings Page Definitions .....</i>	<i>36</i>
<i>Profiles Pages Definitions.....</i>	<i>47</i>
<i>FXS Ports Page Definitions .....</i>	<i>65</i>
Important Settings.....	67
<i>NAT Settings.....</i>	<i>67</i>



<i>DTMF Methods</i> .....	67
<i>Preferred Vocoder (Codec)</i> .....	67
Configuring HT812/HT814 Through Voice Prompts .....	68
Configuration through a Central Server .....	68
Register a SIP Account .....	69
Call Features.....	71
Rebooting HT812/HT814 from Remote .....	72
<b>UPGRADING AND PROVISIONING .....</b>	<b>73</b>
Firmware Upgrade procedure .....	73
Upgrading via Local Directory.....	74
Upgrading via Local TFTP/HTTP/HTTPS/FTP/FTPS Servers .....	74
Firmware and Configuration File Prefix and Postfix .....	74
Managing Firmware and Configuration File Download.....	75
Configuration File Download.....	75
<b>RESTORE FACTORY DEFAULT SETTINGS.....</b>	<b>77</b>
Using the Reset Button.....	77
Using the IVR Command .....	77
Reset from Web Interface (Reset Type) .....	78
Reset using SIP NOTIFY .....	78
<b>EXPERIENCING HT812/HT814.....</b>	<b>79</b>



## Table of Tables

Table 1: HT812/HT814 Features at a Glance .....	15
Table 2: HT812/HT814 Technical Specifications.....	16
Table 3: HT812/HT814 Connectors Definitions .....	19
Table 4: HT812/HT814 LEDs Pattern Description .....	21
Table 5: Voice Prompt Menu .....	22
Table 6: Status Page Definitions .....	28
Table 7: Basic Settings Page .....	30
Table 8: Advanced Settings.....	36
Table 9: Profiles Pages .....	47
Table 10: FXS Ports .....	65
Table 11: HT812/HT814 Call Features.....	71
Table 12: MAC Address Key Mapping .....	77

## Table of Figures

Figure 1: HT812 Package Contents.....	18
Figure 2: HT814 Package Contents.....	18
Figure 3: HT812 Back Panel .....	19
Figure 4: HT814 Back Panel .....	19
Figure 5: Connecting the HT812/HT814 .....	20
Figure 6: HT812/HT814 LEDs Pattern .....	20
Figure 7: Admin Level Password .....	26
Figure 8: User Level Password .....	27
Figure 9: Viewer Level Password.....	27
Figure 10: Web HTTP Port.....	28
Figure 11: SIP Profiles Settings .....	70
Figure 12: SIP Accounts settings .....	70
Figure 13: Accounts Status .....	71
Figure 14: Firmware Upgrade Page.....	73
Figure 15: XML Config File - MAC Header .....	76



## DOCUMENT PURPOSE

This document describes the basic concept and tasks necessary to use and configure your HT812/HT814. It also covers the topic of connecting and configuring the HT812/HT814, making basic operations and the call features. Please visit <https://www.grandstream.com/support> to download the latest “HT812/HT814 User Guide”.

This guide covers following topics:

- [Product overview](#)
- [Getting started](#)
- [Configuration guide](#)
- [Upgrade and provisioning](#)
- [Restore factory default settings](#)





## CHANGE LOG

This section documents significant changes from previous versions of admin guide for HT812/HT814. Only major new features or major document updates are listed here. Minor updates for corrections or editing are not documented here.

### Firmware Version 1.0.35.4

- Added support to allow HT8xx provision admin password without special characters. [UPGRADING AND PROVISIONING]
- Added support for Israel time zone with DST. [Time Zone]

### Firmware Version 1.0.33.4

- Added feature Special Proceed Indication Tone. [Special Proceed Indication Tone].
- Added feature MWI Tone. [MWI Tone].

### Firmware Version 1.0.31.1

- Added support to always send HTTP Basic Authentication Information. [Always Send HTTP Basic Authentication Information]
- Added support to Enable Call Waiting Alert-Info in 180 Ringing Response. [Enable Call Waiting alert-info In 180 Ringing Response]

### Firmware Version 1.0.29.8

- Added support to authenticate based on OpenVPN Username and OpenVPN Password. [OpenVPN Username and OpenVPN Password]
- Added feature “OnHook DC Feed Current” [OnHook DC Feed Current]

### Firmware Version 1.0.27.2

- No Major Changes

### Firmware Version 1.0.25.5

- Added support for “OpenVPN”. [OpenVPN]
- Added support of “Maximum Number of SIP Request Retries”. [Maximum Number of SIP Request Retries]
- Added support for “Failback Timer”. [Failback Timer]

### Firmware Version 1.0.23.5

- Added Special Feature IZZI to support N-Way conference hosted on Nokia IMS.



- Added support for “DNS SRV Failover Mode”. [DNS SRV Failover Mode]
- Added support of “Register before DNS SRV Failover”. [Register before DNS SRV Failover]

### **Firmware Version 1.0.21.4**

- Added support for IPv6 address without square brackets. [Primary SIP Server][Failover SIP Server][Outbound Proxy][Backup Outbound Proxy]
- Added support for DHCP Domain Name configuration. [DHCP domain name]
- Added support of “Use Configured IP” for “DNS Mode”. [Use Configured IP]
- Added support for “Play Busy Tone When Account is unregistered”. [Play Busy Tone When Account is unregistered]

### **Firmware Version 1.0.19.11**

- Added “Disable” option for “Web Access Mode” feature. [Web Access Mode]
- Moved “Trusted CA certificates” from ProfileX to Advanced Settings and renamed as Trusted CA Certificates A and Trusted CA Certificates B. [Trusted CA Certificates (A,B)]
- Added feature “Disable User Level Web Access” and “Disable Viewer Level Web Access”. [Disable User Level Web Access ][Disable Viewer Level Web Access]
- Added feature “Use P-Asserted-Identity Header”. [Use P-Asserted-Identity Header]
- Added feature “Load CA Certificates”. [Load CA Certificate]
- Added support to configure TR-069 connection request port. [Connection Request Port]
- Added OI\_BR to special feature. [Special Feature]
- Added New Zealand Standard for Pulse Dialing Standard. [ Pulse Dialing Standard]
- Added support to set Ring Timeout to 0 for unlimited ring timeout. [Ring Timeout]
- Increased “SIP TLS Certificate” and “SIP TLS Private Key” supported maximum length from 2048 to 4096. [SIP TLS Certificate][SIP TLS Private Key]

### **Firmware Version 1.0.17.5**

- Added feature “Minimum TLS Version”. [Minimum TLS Version]
- Added feature “Maximum TLS Version”. [Maximum TLS Version]
- Updated “São Paulo” time zone to UTC-3. [Time Zone]

### **Firmware Version 1.0.15.4**

- Added more choices to feature “Disable Weak TLS Ciphers”. [Disable Weak TLS Cipher Suites]
- Added feature “Syslog Protocol”. [Syslog Protocol]
- Added support for “Distinctive Call Waiting Tone”. [Distinctive Call Waiting Tone]
- Added support for “Call Waiting Tones”. [Call Waiting Tones]
- Added support for DHCP option 67. [Configuration File Download]
- Added support to allow CID name fields for ports that are part of the active hunting group to take effect. [Hunting Group]



- Added support for GDMS. [ACS URL]

### **Firmware Version 1.0.13.7**

- Added ability to support provisioning server path containing the server authentication credentials for the DHCP option 66. [Allow DHCP Option 66 to Override Server]
- Added support to send SNMP trap to 3 different servers. [SNMP Trap IP Address]
- Added feature “Call Features Settings”. [Call Features Settings]
- Added feature “Use SIP User Agent”. [SIP User-Agent]
- Updated “Use SIP User Agent Header” to “SIP User Agent Postfix”. [SIP User Agent Postfix].
- Added feature “Disable Reminder Ring for DND”. [Disable Reminder Ring for DND]
- Added feature “CDR File Option”. [CDR File Option]
- Added feature “SIP File Option”. [SIP File Option]
- Added feature “Disable Weak TLS Cipher Suites”. [Disable Weak TLS Cipher Suites]
- Added feature “Pulse Dialing Standard”. [Pulse Dialing Standard]
- Added feature “Callee Flash to 3WC”. [Callee Flash to 3WC]
- Added feature “RFC2833 Count”. [RFC2833 Events Count] [RFC2833 End Events Count]
- Added feature “Replace Beginning ‘+’ with 00 in Caller ID”. [Replace Beginning ‘+’ with 00 in Caller ID]
- Added feature “Reset Call Features”. [Reset Call Features]
- Added support to view, download, and delete the call history through device Web UI. [CDR File]
- Added support to store SIP file locally. [SIP File]

### **Firmware Version 1.0.11.6**

- Added “CPU Load” on Web UI status page [CPU Load]
- Added support for SIP keep-alive to use SIP NOTIFY. [Enable SIP OPTIONS/NOTIFY Keep Alive]
- Added feature “Network Cable Status” on Web UI status page. [Network Cable Status]
- Added support for Management Interface. [Management Interface]
- Added feature “SSH Idle Timeout”. [SSH Idle Timeout]
- Added feature “Telnet Idle Timeout”. [Telnet Idle Timeout]
- Added feature “Use ARP to detect network connectivity”. [Use ARP to detect network connectivity]
- Added feature “Call Record”.

### **Firmware Version 1.0.10.6**

- Added feature “Inband DTMF Duration”. [Inband DTMF Duration]
- Added feature “RFC2543 Hold”. [RFC2543 Hold]
- Added feature “Visual MWI Type”. [Visual MWI Type]
- Added feature “Disable Unknown Caller ID”. [Disable Unknown Caller ID]
- Added feature “Disable # as Redial Key”. [Disable # as Redial Key]
- Added feature “Ring Frequency”. [Ring Frequency]
- Added feature “Allow SIP Factory Reset”. [Allow SIP Factory Reset] [Reset using SIP NOTIFY]
- Added support for G722 Codec. [HT812/HT814 Technical Specifications]



- Added support to allow user to choose preference codec from PCMU and PCMA for FAX pass-through codec. [Fax Mode]
- Added Web menu in Spanish. [Language]

### **Firmware Version 1.0.9.3**

- Added feature “Custom Certificate”. [Custom Certificate]
  - Added feature “Use P-Access-Network-Info Header”. [Use P-Access-Network-Info Header]
  - Added feature “Use P-Emergency-Info Header”. [Use P-Emergency-Info Header]
- Added feature “Conference Party Hangup Tone” when “Special Feature” is set to MTS. [Call Progress Tones]
- Add support for HTTPS based on TLS v1.2

### **Firmware Version 1.0.8.7**

- Added [CenturyLink, MTS] to Special Feature.
- Added support for Russian in Web UI and IVR. [Language]
- Added support for upgrade device via FTP/FTPS server. [UPGRADING AND PROVISIONING]
- Added support to have the call waiting tone through SIP INFO.
- Added support for Hunting Group on HT812 Web UI.
- Added feature “Validate Server Certificates”. [Validate Server Certificates]
- Added support for [DDNS]
- Added feature Blacklist for Incoming Calls. [Blacklist for Incoming Calls]
- Added support for [Telnet]
- Added feature [Play busy/reorder tone before Loop Current Disconnect]

### **Firmware Version 1.0.5.11**

- Changed default "Upgrade Via" from HTTP to HTTPS. [Upgrade via] [Upgrade Protocol] [UPGRADE PROTOCOL] [UPGRADING AND PROVISIONING]
- Added the ability to schedule [Automatic Reboot]
- Added support for [SNMPv3]
- Added support for 3 level access through RADIUS authorization (Admin, User and [viewer])
- Added option to customize number of failed [Web Access Attempt Limit] to access web GUI
- Added option to customize idle time to logout the web access with [Web Session Timeout]
- Added option to disable WAN side ports [Black List for WAN Side Port]
- Added feature “Caller ID Fetch Order” option under FXS port settings. [Caller ID Fetch Order]
- Added feature “Enable High Ring Power” option under FXS port settings. [Enable High Ring Power]
- Added feature “Internet Protocol” to choose from “IPv4 Only”, “IPv6 Only”, “Both, prefer IPv4”, “Both, prefer IPv6”. [Internet Protocol]
- Added feature “IPv6 Address” to configure IPv6 Address. [IPv6 Address]



### **Firmware Version 1.0.3.7**

- Added option “Use Actual Ephemeral Port in Contact with TCP/TLS” to force device to use actual ephemeral port. [Use Actual Ephemeral Port in Contact with TCP/TLS]
- Added option “SIP URI Scheme When Using TLS” to choose between ‘SIP’ and ‘SIPS’. [SIP URI Scheme When Using TLS]
- Added Option “Backup Outbound Proxy” to use backup Outbound Proxy if Outbound Proxy registration expires. [Backup Outbound Proxy]
- Added option “Prefer Primary Outbound Proxy” to enable registration through primary outbound proxy if registration expires. [Prefer Primary Outbound Proxy]
- Added option “Enable RTCP” to enable RTCP function through Web UI. [Enable RTCP]
- Added option “Hold Target Before Refer” to enable device to hold before being referred. [Hold Target Before Refer]
- Added Option “Enable Session Timer” to disable session timer. [Enable Session Timer]
- Added feature “Conference URI” to support Conference URI. [Conference URI]
- Added feature “White List for WAN Side” for remote management. [White List for WAN Side]
- Added feature “Black List for WAN Side” for remote management. [Black List for WAN Side]
- Added option “Web Access Mode” to choose between “HTTPS” and “HTTP” to access device Web UI. [Web Access Mode]
- Added feature “HTTPS Web Port” to set HTTPS web port instead of using default HTTPS port. [HTTPS Web Port]
- Added feature “SSH Port” to self-configure SSH port. [SSH Port]
- Added SNMP related features.

### **Firmware Version 1.0.3.2**

- Added option “DNS SRV use Registered IP” to force DNS SRV to use registered IP instead of use first SRV. [DNS SRV use Registered IP]
- Changed default NTP server from us.pool.ntp to pool.ntp.org.

### **Firmware Version 1.0.2.7**

- No major changes

### **Firmware Version 1.0.2.5**

- Changed OPUS Payload Type default value to 123 to match other GS products. [OPUS Payload Type]

### **Firmware Version 1.0.2.3**

- Added network check mechanism to enable or disable WAN port web access.
- Added a re-enter box to confirm change user and admin password on web GUI to avoid typo or mistakes.



[Confirm End User Password] [Confirm Admin Password]

### **Firmware Version 1.0.2.1**

- This is the initial version for HT812/HT814.



## WELCOME

The HT812/HT814 analog telephone adaptors (ATAs) provide transparent connectivity for analog phones and faxes to the world of internet voice. Connecting to any analog phone, fax, or PBX, the HT812/HT814 is an effective and flexible solution for accessing internet-based telephone services and corporate intranet systems across established LAN and internet connections. This Grandstream Handy Tones are a new addition to the popular Handy Tone ATA product family. This manual will help you to learn how to operate and manage your HT812/HT814 analog telephone adaptors and make the best use of their many upgraded features including simple and quick installation, 3-way conferencing, direct IP-IP Calling, and new provisioning support among other features. The HT812/HT814 are very easy to manage and configure, and they are specifically designed to be an easy to use and affordable VoIP solution for both the residential user and the teleworker.




## PRODUCT OVERVIEW

The HT812/HT814 are 2/4 ports analog telephone adaptors (ATAs) that allow users to create a high-quality and manageable IP telephony solution for residential and office environments. Their ultra-compact size, voice quality, advanced VoIP functionality, security protection and auto provisioning options enable users to take advantage of VoIP on analog phones and enables service providers to offer high quality IP service. The HT812/HT814 are an ideal ATAs for individual use and for large scale commercial IP voice deployments since they permit small and medium businesses to create integrated IP and PSTN telephony systems that efficiently manage communication costs. HT812/HT814's inclusion of an integrated NAT router and dual 10/100/1000Mbps Ethernet WAN and LAN ports enables a shared broadband connection between multiple Ethernet devices as well as the extension of VoIP services to analog phones.

### Feature Highlights

The following table contains the major features of the HT812/HT814:

**Table 1: HT812/HT814 Features at a Glance**

<p><b>HT812 / HT814</b></p> 	<ul style="list-style-type: none"> <li>• Support 2 SIP profiles through 2 FXS ports for HT812 and 4 FXS port for HT814 and dual 10/100/1000Mbps Ethernet port for HT812</li> <li>• Support 3-way voice conferencing.</li> <li>• Support wide range of caller ID formats.</li> <li>• Support advanced telephony features, including call transfer, call forward, call-waiting, do not disturb, message waiting indication, multi-language prompts, flexible dial plan and more.</li> <li>• Support T.38 Fax for creating Fax-over-IP.</li> <li>• TLS and SRTP security encryption technology to protect calls and accounts.</li> <li>• Automated provisioning options include TR-069 and XML config files.</li> <li>• Failover SIP server automatically switches to secondary server if main server loses connection.</li> <li>• Use with Grandstream's UCM series of IP PBXs for Zero Configuration provisioning.</li> <li>• GR-909 Line Testing Functionalities.</li> </ul>
---	--



## HT812/HT814 Technical Specifications

The following table resumes all the technical specifications including the protocols/standards supported, voice codecs, telephony features, languages, and upgrade/provisioning settings for the HT812/HT814.

**Table 2: HT812/HT814 Technical Specifications**

Interfaces	
<b>Telephone Interfaces</b>	Two (2) RJ11 FXS ports for HT812. Four (4) RJ11 FXS sports for HT814.
<b>Network Interface</b>	Two (2) 10/100/1000 Mbps Ethernet port (RJ45).
<b>LED Indicators</b>	POWER, LAN, WAN, PHONE1, PHONE2 for HT812. POWER, LAN, WAN, PHONE1, PHONE2, PHONE3, PHONE4 for HT814.
<b>Factory Reset Button</b>	Yes.
Voice, Fax, Modem	
<b>Telephony Features</b>	Caller ID display or block, call waiting, flash, blind or attended transfer, forward, hold, do not disturb, 3-way conference.
<b>Voice Codecs</b>	G.711 with Annex I (PLC) and Annex II (VAD/CNG), G.723.1, G.729A/B, G.722, G.726, iLBC, OPUS, dynamic jitter buffer, advanced line echo cancellation.
<b>Fax over IP</b>	T.38 compliant Group 3 Fax Relay up to 14.4kpbs and auto-switch to G.711 for Fax Pass-through.
<b>Short/Long Haul Ring Load</b>	For HT812: 3 REN, up to 1km on 24AWG line. For HT814: 2 REN, up to 1km on 24AWG line.
<b>Caller ID</b>	Bellcore Type 1 & 2, ETSI, BT, NTT, and DTMF-based CID.
<b>Disconnect Methods</b>	Busy Tone, Polarity Reversal/Wink, Loop Current.
Signaling	
<b>Network Protocols</b>	TCP/IP/UDP, RTP/RTCP, HTTP/HTTPS, FTP/FTPS, ARP/RARP, ICMP, DNS, DDNS, DHCP, NTP, TFTP, SSH, Telnet, STUN, SIP (RFC3261), SIP over TCP/TLS, SRTP, TR-069.
<b>QoS</b>	Layer 2 (802.1Q VLAN, SIP/RTP 802.1p) and Layer 3 (ToS, DiffServ, MPLS).
<b>DTMF Methods</b>	In-audio, RFC2833 and/or SIP INFO.
<b>Provisioning and Control</b>	HTTP, HTTPS, SSH, FTP, FTPS, Telnet, TFTP, TR-069, secure and automated provisioning using TR069, syslog.
Security	
<b>Media</b>	SRTP.




<b>Control</b>	TLS/SIPS/HTTPS/HTTP/SSH/Telnet.
<b>Management</b>	Syslog support, SSH, Telnet remote management using web browser.
<b>Physical</b>	
<b>Universal Power Supply</b>	Input: 100-240VAC, 50-60Hz Output: 12V/0.5A for HT812. Output: 12V/1A for HT814.
<b>Environmental</b>	Operational: 32° – 104°F or 0° – 40°C. Storage: 14° – 140°F or -10° – 60°C. Humidity: 10 – 90% Non-condensing.
<b>Dimensions and Weight</b>	Dimension : 28.5 x 130 x 90 mm (H x W x D). Weight: 353.33g for HT812 and for 423.5g for HT814.
<b>Compliance</b>	
<b>Compliance</b>	FCC/CE/RCM.

## GETTING STARTED


This chapter provides basic installation instructions including the list of the packaging contents and also information for obtaining the best performance with the HT812/HT814.

### Equipment Packaging

The HT812/HT814 ATAs packages contain:



**Figure 1: HT812 Package Contents**



**Figure 2: HT814 Package Contents**

**Note:** Check the package before installation. If you find anything missing, contact your system administrator.

## HT812/HT814 Ports Description

The following figure describes the different ports on the back panel of the HT812/HT814.




Figure 3: HT812 Back Panel






Figure 4: HT814 Back Panel

Table 3: HT812/HT814 Connectors Definitions

<b>Phone 1 &amp; 2 (HT812)</b> <b>Phone 1,2,3 &amp; 4 (HT814)</b>	Connects the analog phones / fax machines to the ATA using an RJ-11 telephone cable.
<b>WAN</b> 	Connects the ATA to your router, switch or modem using an Ethernet RJ45 network cable.
<b>LAN</b> 	Connects the ATA to your PC or switch using an Ethernet RJ45 network cable.
<b>DC Power</b>	Connects the ATA to PSU (12V – 0.5A for HT812) and (12V - 1A for HT814).
<b>Reset</b>	Factory reset button. Press for 7 seconds to reset factory default

## Connecting HT812/HT814

The HT812/HT814 are designed for easy configuration and easy installation, to connect your HT812/HT814, please follow the steps below:

### Scenario 1: Connecting the HT812/HT814 using WAN Port

When connecting HT812/HT814 using the WAN port, they will act as simple DHCP Client.

1. Insert a standard RJ11 telephone cable into the phone ports and connect the other end of the telephone cable to a standard touch-tone analog telephone.
2. Connect the WAN port of the HT812/HT814 to a router, switch or modem using an Ethernet cable.
3. Insert the power adapter into the HT812/HT814 and connect it to a wall outlet and make sure to respect the technical specifications of the power adapter used.
4. Power, WAN and Phone LEDs will be solidly lit when the HT812/HT814 is ready for use.



## Scenario 2: Connecting the HT812/HT814 using LAN Port

When connecting the HT812/HT814 using the LAN port, they will act as a router and DHCP serving addresses, the devices connected with HT812/HT814 LAN will pull DHCP addresses from your HT812/HT814.

1. Insert a standard RJ11 telephone cable into the phone ports and connect the other end of the telephone cable to a standard touch-tone analog telephone.
2. Connect a computer or switch to the LAN port of the HT812/HT814 using an Ethernet Cable.
3. Insert the power adapter into the HT812/HT814 and connect it to a wall outlet and make sure to respect the technical specifications of the power adapter used.
4. Power, LAN, and Phone LEDs will be solidly lit when the HT812/HT814 is ready for use.

**Note:** Please make sure to enable NAT Router under Web GUI → Basic Settings → Device Mode.




Figure 5: Connecting the HT812/HT814

## HT812/HT814 LEDs Pattern

There are four (4) LED types that help you manage the status of your HT812/HT814.



Figure 6: HT812/HT814 LEDs Pattern

**Table 4: HT812/HT814 LEDs Pattern Description**

LED Lights	Status
<b>Power LED</b>	The Power LED lights up when the HT812/HT814 are powered on and it flashes when the HT812/HT814 is booting up.
<b>WAN LED</b>	The WAN LED lights up when the HT812/HT814 are connected to your network through the WAN port.
<b>LAN LED</b>	The LAN LED lights up when the HT812/HT814 are connected to your network through the LAN port.
<b>Phone LED 1&amp;2 (HT812)</b> <b>Phone LED 1,2,3 &amp; 4 (HT814)</b>	The phone LEDs indicate status of the respective FXS port-phone on the back panel <ul style="list-style-type: none"> <li>• <b>OFF</b> - Unregistered</li> <li>• <b>ON (Solid Blue)</b> - Registered and Available</li> <li>• <b>Blinking every 500 ms</b> - Off-Hook / Busy</li> <li>• <b>Slow blinking</b> - FXS LEDs indicates voicemail</li> </ul>

## CONFIGURATION GUIDE

The HT812/HT814 can be configured via one of two ways:

- The IVR voice prompt menu.
- The Web GUI embedded on the HT812/HT814 using PC's web browser.

### Obtain HT812/HT814 IP Address via Connected Analogue Phone

HT812/HT814 are by default configured to obtain the IP address from DHCP server where the unit is located. To know which IP address is assigned to your HT812/HT814, you should access to the "[Interactive Voice Response Menu](#)" of your adapter via the connected phone and check its IP address mode.

Please refer to the steps below to access the interactive voice response menu:

1. Use a telephone connected to phone ports (FXS) of your HT812/HT814.
2. Press \*\*\* (press the star key three times) to access the IVR menu and wait until you hear "Enter the menu option".
3. Press 02 and the current IP address will be announced.

### Understanding HT812/HT814 Interactive Voice Prompt Response Menu

The HT812/HT814 have a built-in voice prompt menu for simple device configuration which lists actions, commands, menu choices, and descriptions. The IVR menu works with any phone connected to the HT812/HT814.

Pick up the handset and dial "\*\*\*\*" to use the IVR menu.

Table 5: Voice Prompt Menu

Menu	Voice Prompt	Options
<b>Main Menu</b>	"Enter a Menu Option"	Press "*" for the next menu option Press "#" to return to the main menu Enter 01-05, 07, 10, 12-17, 47 or 99 menu options
<b>01</b>	"DHCP Mode", "Static IP Mode" "PPPoE Mode"	Press "9" to toggle the selection If using "Static IP Mode", configure the IP address information using menus 02 to 05. If using "Dynamic IP Mode", all IP address information comes from the DHCP server automatically after reboot. If using "PPPoE Mode", configure PPPoE Username and Password from web GUI to get IP from your ISP.



<b>02</b>	“IP Address“ + IP address	The current WAN IP address is announced If using “Static IP Mode”, enter 12-digit new IP address. <b>You need to reboot your HT812/HT814 for the new IP address to take Effect.</b>
<b>03</b>	“Subnet“ + IP address	Same as menu 02
<b>04</b>	“Gateway“ + IP address	Same as menu 02
<b>05</b>	“DNS Server“ + IP address	Same as menu 02
<b>07</b>	Preferred Vocoder	Press “ <b>9</b> ” to move to the next selection in the list: <ul style="list-style-type: none"> <li>• PCM U / PCM A</li> <li>• iLBC</li> <li>• G-726</li> <li>• G-723</li> <li>• G-729</li> <li>• OPUS</li> <li>• G722</li> </ul>
<b>10</b>	“MAC Address”	Announces the MAC address of the unit. <b>Note:</b> The device has two MAC addresses. One for the WAN port and one for the LAN port. The device MAC address announced is the address of LAN port.
<b>12</b>	WAN Port Web Access	Press “ <b>9</b> ” to toggle between <b>enable / disable</b> . Default is disabled.
<b>13</b>	Firmware Server IP Address	Announces current Firmware Server IP address. Enter 12-digit new IP address.
<b>14</b>	Configuration Server IP Address	Announces current Config Server Path IP address. Enter 12-digit new IP address.
<b>15</b>	Upgrade Protocol	Upgrade protocol for firmware and configuration update. Press “ <b>9</b> ” to toggle between <b>TFTP / HTTP / FTP / FTPS</b> or <b>HTTPS</b> . Default is HTTPS.
<b>16</b>	Firmware Version	Announces Firmware version information.
<b>17</b>	Firmware Upgrade	Firmware upgrade mode. Press “ <b>9</b> ” to toggle among the following three options: <ul style="list-style-type: none"> <li>• Always check</li> <li>• Check when pre/suffix changes</li> <li>• Never upgrade</li> </ul>





<b>47</b>	“Direct IP Calling”	Enter the target IP address to make a direct IP call, after dial tone. (See “ <i>Make a Direct IP Call</i> ”.)
<b>86</b>	Voice Mail	Access to your voice mails messages.
<b>99</b>	“RESET”	Press “9” to reboot the device Enter MAC address to restore factory default setting (See <b>Restore Factory Default Setting</b> section)
	“Invalid Entry”	Automatically returns to main menu
	“Device not registered”	This prompt will be played immediately after off hook If the device is not registered, and the option “Outgoing Call without Registration” is in NO

### Five success tips when using the voice prompt

- “\*” shifts down to the next menu option and “#” returns to the main menu
- “9” functions as the ENTER key in many cases to confirm or toggle an option.
- All entered digit sequences have known lengths - 2 digits for menu option and 12 digits for IP address. For IP address, add 0 before the digits if the digits are less than 3 (i.e. - 192.168.0.26 should be key in like 192168000026. No decimal is needed).
- Key entry cannot be deleted but the phone may prompt error once it is detected.

**Note:** Please make sure to reboot the device after changing network settings (IP Address, Gateway, Subnet...) to apply the new configuration.

### Configuration via Web Browser

The HT812/HT814 embedded Web server responds to HTTP GET/POST requests. Embedded HTML pages allow a user to configure the HT812/HT814 through a web browser such as Google Chrome, Mozilla Firefox, and Microsoft's IE.

- **Microsoft Internet Explorer:** version 10 or higher.
- **Google Chrome:** version 58.0.3 or higher.
- **Mozilla Firefox:** version 53.0.2 or higher.
- **Safari:** version 5.1.4 or higher.
- **Opera:** version 44.0.2 or higher.



## Accessing the Web UI

### - Via WAN port

For the initial setup, the Web access is by default enabled when the device is using private IP and disabled when using public IP, and you cannot access the Web UI of your HT812/HT814 until it's enabled, the following steps will show you how to enable it via IVR.

1. Power your HT812/HT814 using PSU with the right specifications.
2. Connect your analog phone to phone ports (FXS) of your HT812/HT814.
3. Press \*\*\* (press the star key three times) to access the IVR menu and wait until you hear "Enter the menu option".
4. Press 12, the IVR menu will announce that the web access is disabled, press 9 to enable it.
5. Reboot your HT812/HT814 to apply the new settings.

Please refer to steps below if your HT812/HT814 is connected via WAN port:

1. You may check your HT812/HT814 IP address using the IVR on the connected phone.

Please see [Obtain the HT812/HT814 IP address via the connected analogue phone](#)

2. Open the web browser on your computer.
3. Enter the HT812/HT814's IP address in the address bar of the browser.
4. Enter the administrator's password to access the Web Configuration Menu.

**Note:** The computer must be connected to the same sub-network as the HT812/HT814. This can be easily done by connecting the computer to the same hub or switch as the HT812/HT814.

### - Via LAN port

Please refer to steps below if your HT812/HT814 is connected via LAN port:

1. Power your HT812/HT814 using PSU with the right specifications.
2. Connect your computer or switch directly to your HT812/HT814 LAN port.
3. Open the web browser on your computer.
4. Enter the default LAN IP address (192.168.2.1) in the address bar of the browser.
5. Enter the administrator's password to access the Web Configuration Menu.
6. Make sure to reboot your device after changing your settings to apply the new configuration.

**Note:** Please make sure that your computer has a valid IP address on the range 192.168.2.x so you can access the web GUI of your HT812/HT814.



## Web UI Access Level Management

There are three default passwords for the login page:

User Level	Password	Web Pages Allowed
End User Level	123	Only Status and Basic Settings
Administrator Level	admin	All pages
Viewer Level	viewer	Only checking. Not allowed to modify content.


The password is case sensitive with maximum length of 25 characters. When changing any settings, always submit them by pressing **Update** or **Apply** button on the bottom of the page. After submitting the changes in all the Web GUI pages, if a reboot is required, the web page will prompt the user to reboot by offering a reboot button on the web page.

## Saving the Configuration Changes

After users make changes to the configuration, pressing **Update** button will save but not apply the changes until **Apply** button is clicked. Users can instead directly press **Apply** button. When a reboot is required to apply changes, the web page will prompt the user to reboot by offering a reboot button on the web page.

## Changing Admin Level Password

1. Access your HT812/HT814 web UI by entering its IP address in your favorite browser.
2. Enter your admin password (default: admin).
3. Press **Login** to access your settings.
4. Go to **Advanced Settings** → **New Admin Password** and enter the new admin password.
5. Confirm the new admin password.
6. Press **Apply** at the bottom of the page to save your new settings.




The screenshot shows the 'Grandstream Device Configuration' web interface. At the top, there are navigation tabs: STATUS, BASIC SETTINGS, **ADVANCED SETTINGS** (highlighted with a red box), PROFILE 1, PROFILE 2, and FXS PORTS. Below the tabs, there are two input fields: 'New Admin Password:' (highlighted with a red box) and 'Confirm Admin Password:' (highlighted with a red box). The 'New Admin Password' field has a placeholder text '(purposely not displayed for security protection)'.

Figure 7: Admin Level Password

## Changing User Level Password

1. Access your HT812/HT814 web UI by entering its IP address in your favorite browser.
2. Enter your admin password (default: admin).
3. Press **Login** to access your settings.

4. Go to **Basic Settings** → **New End User Password** and enter the new end-user password.
5. Confirm the new end-user password.
6. Press **Apply** at the bottom of the page to save your new settings.



**Grandstream Device Configuration**


STATUS **BASIC SETTINGS** ADVANCED SETTINGS PROFILE 1 PROFILE 2 FXS PORTS

**New End User Password:**  (purposely not displayed for security protection)  
**Confirm End User Password:**

Figure 8: User Level Password

### Changing Viewer Password

1. Access your HT812/HT814 web UI by entering its IP address in your favorite browser.
2. Enter your admin password (default: admin).
3. Press **Login** to access your settings.
4. Go to **Basic Settings** → **New Viewer Password** and enter the new viewer password.
5. Confirm the new viewer password.
6. Press **Apply** at the bottom of the page to save your new settings.



**Grandstream Device Configuration**

STATUS **BASIC SETTINGS** ADVANCED SETTINGS PROFILE 1 PROFILE 2 FXS PORTS

**New End User Password:**  (purposely not displayed for security protection)  
**Confirm End User Password:**

**New Viewer Password:**  (purposely not displayed for security protection)  
**Confirm Viewer Password:**

Figure 9: Viewer Level Password

### Changing HTTP Web Port

1. Access your HT812/HT814 web UI by entering its IP address in your favorite browser.
2. Enter your admin password (default: admin).
3. Press **Login** to access your settings.
4. Go to **Basic Settings** → **HTTP Web Port**.
5. Make sure that the **Web Access Mode** is set to **HTTP**.
6. Change the current port to your desired/new HTTP port. Ports accepted are in range [1-65535].
7. Press **Apply** at the bottom of the page to save your new settings.

Grandstream Device Configuration

STATUS
BASIC SETTINGS
ADVANCED SETTINGS
PROFILE 1
PROFILE 2
FXS PORTS

New End User Password:  (purposely not displayed for security protection)

Confirm End User Password:

New Viewer Password:  (purposely not displayed for security protection)

Confirm Viewer Password:

*Web/SSH Access:*

Web Session Timeout:  (1-60, default 10 minutes.)

Web Access Attempt Limit:  (1-10, default 5.)

Web Lockout Duration:  (0-60, default 15 minutes.)

Web Access Mode:  HTTPS  HTTP

HTTP Web Port:  (default is 80)

HTTPS Web Port:  (default is 443)

Figure 10: Web HTTP Port

## Web Configuration Pages Definitions

This section describes the options in the HT812/HT814 Web UI. As mentioned, you can log in as an administrator or an end user.

- **Status:** Displays the system info, network status, account status, and line options.
- **Basic Settings:** Configures the end user level password, IP address modes, web access, time zone settings and language.
- **Advanced Settings:** Configures networks, upgrading and provisioning, TR-069, security settings, date and time, syslog, audio settings, call settings and call progress tones.
- **Profile (1,2):** Configures the SIP Server, SIP Registration, NAT settings, call features, ring tones.
- **FXS Ports:** Configures SIP accounts settings, Off hook Auto-dial.

## Status Page Definitions

Table 6: Status Page Definitions

Status	
<b>MAC Address</b>	Shows device ID in hexadecimal format. This is needed by network administrators for troubleshooting. The MAC address will be used for provisioning and can be found on the label on original box and on the label located on the bottom panel of the device.



	<p><b>Note:</b> The device has two MAC addresses, one for the WAN port and one for the LAN port. The MAC address located on the bottom panel of the device is the MAC address of LAN port. The MAC address of WAN port is MAC address of LAN port +1.</p> <p>Example: MAC Address: WAN - "00:0B:82:25:AF:32", LAN - "00:0B:82:25:AF:31".</p>
<b>WAN IPv4 Address</b>	Displays assigned IPv4 address.
<b>WAN IPv6 Address</b>	Displays assigned IPv6 address.
<b>VPN IPv4 Address</b>	Displays assigned OpenVPN IPv4 address.
<b>VPN IPv6 Address</b>	Displays assigned OpenVPN IPv6 address.
<b>Product Model</b>	Displays product model info. Default is <b>HT812</b> or <b>HT814</b> .
<b>Hardware Version</b>	Displays the hardware revision information and the part number.
<b>Software version</b>	<ul style="list-style-type: none"> <li>• <b>Program:</b> Specifies Program version. This is the main firmware release number, which is always used for identifying the software system of the HT812/HT814.</li> <li>• <b>Bootloader:</b> Specifies Boot version.</li> <li>• <b>Core:</b> Specifies Core version.</li> <li>• <b>Base:</b> Specifies Base version.</li> <li>• <b>CPE:</b> Specifies CPE version. CPE version is displayed only when HT812/HT814 is connected to an ACS using TR-069 protocol.</li> </ul>
<b>Software Status</b>	Indicates the current software status of the HT (Running or Stopped).
<b>System Up Time</b>	Indicates actual system time and uptime since last reboot.
<b>CPU Load</b>	Indicates CPU load (%)
<b>Network Cable Status</b>	Indicates the Status of the Network cables connected to the LAN Port and the WAN Port. <b>Status</b> (Up/Down), <b>Speed</b> (Mbps), <b>Operational Mode</b> (Full/Half Duplex)
<b>PPPoE Link Up</b>	Indicates PPPoE connection status.
<b>NAT</b>	Indicates type of NAT when it is configured.
<b>Port Status</b>	Displays relevant information regarding the FXS ports about their registration, current status and their appropriate User ID.

<b>Port Options</b>	Displays relevant information regarding the FXS ports about their DND and call forward features.
<b>CDR File</b>	<b>Download, Preview</b> . Or <b>Delete</b> call history records from the web GUI. Only the last 1000 records will be available.
<b>SIP File</b>	<b>Download, Preview</b> or, <b>Delete</b> locally stored SIP trace. <b>Note: "Send SIP Log"</b> must be enabled to be able to capture the trace.
<b>Provision</b>	Displays provisioning status.
<b>Core Dump</b>	Provides generated core dump file if unit malfunctions. <b>Clean</b> will be displayed if no issues.

## Basic Settings Page Definitions

Table 7: Basic Settings Page

Basic Settings	
<b>New End User Password</b>	Configures user level password. Case sensitive and max. length of 25 characters.
<b>Confirm End User Password</b>	Re-enter the end user password to confirm change user password on web GUI to avoid typo or mistakes.
<b>New Viewer Password</b>	Configures viewer level password. Case sensitive and max. Length of 25 characters.
<b>Confirm Viewer Password</b>	Re-enter the viewer password to confirm change viewer password on web GUI to avoid typo or mistakes.
<b>Web Session Timeout</b>	Configure timer to logout web session during idle. Default is 10 min. Range is 2-60 min.
<b>Web Access Attempt Limit</b>	Configure attempt limit before lockout (Default is 5. Range is 1-10).
<b>Lockout time interval</b>	If login attempt failed 5 times, login would be locked out for the time length. (Default 15 mins. Range 1-15 min).
<b>Web Access Mode</b>	Allows users to choose the Web Access Mode between "HTTPS", "HTTP" and "Disabled". If "Disabled" is selected, web UI access will be disabled. By default, "HTTP" is selected.



<b>HTTP Web Port</b>	Customizes HTTP port used to access the HT812/HT814 web UI. Default is <b>80</b> .
<b>HTTPS Web Port</b>	Customizes HTTPS port used to access the HT812/HT814 web UI. Default is <b>443</b> .
<b>Disable SSH</b>	Enables/disables the SSH access. Default is <b>No</b> (disabled).
<b>SSH Port</b>	Allows users to self-configure SSH Port number. By default, the port number is <b>22</b> .
<b>SSH Idle Timeout</b>	Configures the SSH session timeout (0-86400 secs). Default is <b>0</b> .
<b>Disable Telnet</b>	Enables/disables the Telnet access. Default is <b>Yes</b> (disabled).
<b>Telnet Port</b>	Allows users to self-configure Telnet Port number. Default is <b>23</b> .
<b>Telnet Idle Timeout</b>	Configures the Telnet session timeout (0-86400 secs). Default is <b>0</b> .
<b>WAN Side Web/SSH Access</b>	<p>Enables / Disables the Web and SSH access through the WAN port. The available options are the following:</p> <ul style="list-style-type: none"> <li>• <b>No</b>: No access to the web or SSH from any IP address on the WAN side.</li> <li>• <b>Yes</b>: Access for the Web GUI and SSH is enabled on the WAN side.</li> <li>• <b>Auto</b>: Only private IP could access the web or SSH on the WAN side.</li> </ul> <p>Default setting is <b>Auto</b>.</p>
<b>White List for WAN Side</b>	<p>If "WAN Side Web/SSH Access" is set to "Yes" or "Auto". Users can configure the white List for WAN Side to be used for remote management.</p> <p>Multiple IPs are supported and need to be separated by "space".</p> <p><b>Example:</b> 192.168.5.222 192.168.5.223 192.168.7.0/24</p> <p><b>Note:</b> If both blacklist and whitelist are not empty, the blacklist is processed first, followed by the whitelist.</p>
<b>Black List for WAN Side</b>	<p>If "WAN Side Web/SSH Access" is set to "Yes" or "Auto". Users can configure the black List for WAN Side to ban WAN side web access.</p> <p>Multiple IPs are supported and need to be separated by "space".</p>





	<p><b>Example:</b> 192.168.5.222 192.168.5.223 192.168.7.0/24</p> <p><b>Note:</b> If both blacklist and whitelist are not empty, the blacklist is processed first, followed by the whitelist.</p>
<b>Internet Protocol</b>	<p>Selects one of the following IP protocol modes:</p> <ul style="list-style-type: none"> <li>• <b>IPv4 Only:</b> Enforce IPv4 protocol only.</li> <li>• <b>IPv6 Only:</b> Enforce IPv6 protocol only.</li> <li>• <b>Both, Prefer IPv4:</b> Enable both IPv4 and IPv6 and prefer IPv4.</li> <li>• <b>Both, prefer IPv6:</b> Enable both IPv4 and IPv6 and prefer IPv6.</li> </ul> <p><b>Note:</b> Make sure to reboot the ATA for the changes to take effect.</p>
<b>IPv4 Address</b>	<p>Allows users to configure the appropriate network settings on the HT81x to obtain IPv4 address. Users could select "DHCP", "Static IP" or "PPPoE". By default, it is set to "DHCP".</p>
<b>Dynamically assigned via DHCP</b>	<p>All the field values for the static IP mode are not used (even though they are still saved in the flash memory.) The HT801/802 acquires its IP address from the first DHCP server it discovers from the LAN it is connected.</p> <ul style="list-style-type: none"> <li>• <b>DHCP hostname:</b> Specifies the name of the client. The name may or may not be qualified with the local domain name. This field is optional but may be required by ISP.</li> <li>• <b>DHCP domain name:</b> Specifies the domain name that the client should use when resolving hostname via the Domain Name System.</li> <li>• <b>DHCP vendor class ID:</b> Exchanges vendor class ID by clients and servers to convey particular configuration or other identification information about a client. Default is <b>HT8XX</b>.</li> </ul>
<b>Use PPPoE</b>	<p>Set the PPPoE account settings. If selected, ATA attempt to establish a PPPoE session if any of the PPPoE fields is set.</p> <ul style="list-style-type: none"> <li>• <b>PPPoE account ID:</b> Defines the PPPoE username. Necessary if ISP requires you to use a PPPoE (Point to Point Protocol over Ethernet) connection.</li> <li>• <b>PPPoE password:</b> Specifies the PPPoE account password.</li> <li>• <b>PPPoE Service Name:</b> Defines PPPoE service name. If your ISP uses a service name for the PPPoE connection, enter the service</li> </ul>



	name here. This field is optional. Default is blank.
<b>Preferred DNS server</b>	Specifies preferred DNS server to use when DHCP or PPPoE are set.
<b>Statically configured as IP address</b>	Configure IP address, subnet Mask, default router IP address, 1 <sup>st</sup> preferred DNS server, 2 <sup>nd</sup> preferred DNS server. These fields are set to zero by default.
<b>IPv6 Address</b>	<p>Allows users to configure the appropriate network settings on the HT81x to obtain IPv6 address. Users could select "DHCP", "Static IP". By default, it is set to "DHCP".</p> <ul style="list-style-type: none"> <li>• <b>DHCP mode:</b> all the field values for the static IP mode are not used (even though they are still saved in the flash memory.) The ATA acquires its IP address from the first DHCP server it discovers from the LAN it is connected.</li> <li>• <b>Static IP mode:</b> configure IP address, 1<sup>st</sup> and 2<sup>nd</sup> DNS server, preferred DNS server. These fields are set to zero by default. <ul style="list-style-type: none"> <li>- <i>Full Static:</i> When enabling the option full static, users need to specify the Static IPv6 and the IPv6 Prefix length.</li> <li>- <i>Prefix Static:</i> When enabling the option prefix static, users need to specify the IPv6 Prefix (64 bits).</li> </ul> </li> </ul>
<b>Enable Management Interface</b>	Enables the Management Interface, a Virtual Network Interface on top of the physical interface for device management. Default is <b>No</b> .
<b>Management Access</b>	Chooses whether to access using “ <b>Management Interface Only</b> ” (Default) Or “ <b>Both Service and Management Interfaces</b> ”
<b>Management Interface IPv4 Address</b>	<p>Configures Voice VLAN Type :</p> <ul style="list-style-type: none"> <li>• Default is <b>dynamically assigned via DHCP</b> Or,</li> <li>• <b>statically configured as:</b> <ul style="list-style-type: none"> <li>○ IP Address : Default is <b>192.168.100.100</b></li> <li>○ Subnet Mask : Default is <b>255.255.255.0</b></li> <li>○ Default Router : Default is <b>192.168.100.1</b></li> <li>○ DNS Server 1 : Default is <b>0.0.0.0</b></li> <li>○ DNS Server 2 : Default is <b>0.0.0.0</b></li> </ul> </li> <li>• <b>802.1Q/VLAN Tag</b> vlan tagging: [0 – 4094]; Default is <b>0</b></li> </ul>



	<ul style="list-style-type: none"> <li>• <b>802.1p priority value :</b> priority : [0 – 7]; Default is <b>0</b></li> </ul>
<b>Time Zone</b>	Selects time zone to define date/time on the device.
<b>Self-Defined Time Zone</b>	Allows users to define their own time zone.
<b>Allow DHCP server to set Time Zone</b>	Obtains time zone setting (offset) from a DHCP server using DHCP Option 2; it will override selected time zone. If set to “No”, the analogue adapter will use selected time zone even if provided by DHCP server. Default is <b>Yes</b> .
<b>Language</b>	Configures the languages of the voice prompt and web interface. Available languages: English, Chinese, Spanish and Russian.
<b>Device Mode</b>	Controls whether the device is working in NAT router mode or Bridge mode. Save the setting and reboot prior to configuring the HT812/HT814.
<b>NAT Maximum Ports</b>	Defines the number of ports that can be managed while in NAT router mode. Range: 0 – 4096, default is 1024. Typically, one port per connection
<b>NAT TCP Timeout</b>	NAT TCP idle timeout in seconds. Connection will be closed after preconfigured, timeout if not refreshed. Range: 0 - 3600
<b>NAT UDP Timeout</b>	NAT TCP idle timeout in seconds. Connection will be closed after preconfigured, timeout if not refreshed. Range: 0 – 3600, default is 300
<b>Uplink Bandwidth</b>	Specifies the maximum uplink bandwidth permitted by the device. This function is disabled by default. The total bandwidth can be set as: 128K, 256K, 512K, 1M, 2M, 3M, 4M, 5M, 10M or 15M. The primary function of this setting is to limit the uplink bandwidth for the device internal system, signaling and NATed traffic. Example: When 512k is configured, there will be at least 512kbps limited for internal system, signaling and NATed traffic. Voice or RTP stream will never be limited.
<b>Downlink Bandwidth</b>	Specifies the maximum downlink bandwidth permitted by the device. This function is disabled by default. The total bandwidth can be set as: 128K, 256K, 512K, 1M, 2M, 3M, 4M, 5M, 10M or 15M. The primary function of this setting is to limit the download bandwidth for



	the device internal system, signaling and NATed traffic. Example: if 128 is configured, there will be at least 128kbps limited for internal system, signaling and NATed traffic. Voice or RTP stream will never be limited.
<b>Enable UPnP Support</b>	When set to “Yes”, the HT812/HT814 acts as an UPnP gateway for your UPnP enabled applications. <b>UPnP = “Universal Plug and Play”</b>
<b>Reply to ICMP on WAN Port</b>	Default is No. When set to “Yes”, the HT812/HT814 responds to the PING command from other computers, but is also made vulnerable to DOS attacks.
<b>Cloned WAN MAC Address</b>	This allows the user to change/set a specific MAC address on the WAN interface. Note: Set in Hex format
<b>Enable LAN DHCP</b>	When set to “Yes”, device will function as a simple router and LAN port will provide IP addresses to internal network. Connect the WAN port to ADSL/Cable modem or any other equipment that provides access to public Internet
<b>LAN DHCP Base IP</b>	Base IP Address for a LAN port. Default factory setting is 192.168.2.1. Note: When the device detects WAN IP is conflicting with LAN IP, the LAN base IP address will be changed based on the network mask -- the effective subnet will be increased by 1. For example; 192.168.2.1 will be changed to 192.168.3.1 if net mask is 255.255.255.0. Then the device will reboot
<b>LAN DHCP Start IP</b>	Default value is 100. The last segment of IP address assigned to the HT812/HT814 in the LAN Network. Default configuration assigns IP address (to local network devices) starting from 192.168.2.100.
<b>LAN DHCP End IP</b>	Default value is 199. This parameter allows a user to limit the number of local network devices connected to the internal router. Default configuration assigns IP address (to devices connected to the LAN port) in a range from 192.168.2.100 up to 192.168.2.199.
<b>LAN Subnet Mask</b>	Sets the LAN subnet mask. Default value is 255.255.255.0



<b>DHCP IP Lease Time</b>	Default value is 120 hrs (5 days). The length of time the IP address is assigned to the LAN clients. Value is set in units of hours.
<b>DMZ IP</b>	This function forwards all WAN IP traffic to a specific IP address if no matching port is used by HT812/HT814 or in the defined port forwarding.
<b>Port Forwarding</b>	Forwards a matching (TCP/UDP) port to a specific LAN IP address with a specific (TCP/UDP) port. Up to 8 rules are available.
<b>Reset Type</b>	<p>Gives the administrator the option to restore default configuration on the HT812/HT814.</p> <p>There are 3 types of factory reset:</p> <ul style="list-style-type: none"> <li>• <b>ISP Data Reset:</b> All VoIP related configuration (mainly everything located on FXS page).</li> <li>• <b>VoIP Data Reset:</b> All ISP (Internet Service Provider) configuration which may affect the IP address.</li> <li>• <b>Full Reset:</b> Both VoIP and ISP related configuration at the same time.</li> </ul> <p><b>Note:</b> After choosing reset type, you will have to click the reset button for it to take effect.</p>

## Advanced Settings Page Definitions

Table 8: Advanced Settings

Advanced Settings	
<b>New Admin Password</b>	<p>Defines the administrator level password to access the Advanced Web Configuration page.</p> <p>This field is case sensitive. Only the administrator can configure the “Advanced Settings” page. Password field is purposely left blank for security reasons after clicking update and saved.</p> <p>The maximum password length is 30 characters.</p>
<b>Confirm Admin Password</b>	Re-enter the admin password to confirm change admin password on web GUI to avoid typo or mistakes.
<b>Disable User Level Web Access</b>	This feature allows the user to enable or disable user Web access. Default setting is No.



<b>Disable Viewer Level Web Access</b>	This feature allows the user to enable or disable Viewer Web access. Default setting is No.
<b>Layer 2 QoS</b>	Sets values for: 802.1Q/VLAN Tag. Default is <b>0</b> . Valid range is 0-4094. SIP 802.1p. Default is <b>0</b> . Valid range is 0-7. RTP 802.1p. Default is <b>0</b> . Valid range is 0-7.
<b>Black List for WAN Side Port</b>	It could be either port range or single port separated by a “,” Example: “5000-6000, 7000 “.
<b>STUN Server</b>	Configures IP address or domain name of STUN server. Only non-symmetric NAT routers work with STUN.
<b>Keep-alive interval</b>	Sends periodically a blank UDP packet to SIP server in order to keep the "ping hole" on the NAT router open. Default is <b>20</b> seconds.
<b>Use STUN to detect network connectivity</b>	Uses STUN keep-alive to detect WAN side network problems. If keep-alive request does not yield any response for configured number of times (minimum 3), the device will restart the TCP/IP stack. If the STUN server does not respond when the device boots up, the feature is disabled. Default setting is <b>No</b> .
<b>Use DNS to detect network connectivity</b>	Uses DNS to detect WAN side network problems. Default setting is <b>No</b> .
<b>Use ARP to detect network connectivity</b>	Uses ARP to check the network connectivity. Default is <b>Yes</b> .
<b>Verify host when using HTTPS</b>	Enables / disables the host verification when using HTTPS.
<b>Upgrade via</b>	Selects firmware upgrade/provisioning method: TFTP, HTTP, HTTPS, FTP, or FTPS. Default is HTTPS.
<b>Firmware Server Path</b>	Sets IP address or domain name of firmware server. The URL of the server that hosts the firmware release. Default is <b>fm.grandstream.com/gs</b> .
<b>Config Server Path</b>	Sets IP address or domain name of configuration server. The server hosts a copy of the configuration file to be installed on the HT812/HT814. Default is <b>fm.grandstream.com/gs</b> .



<b>XML Config File Password</b>	Decrypts XML configuration file when encrypted. The password used for encrypting the XML configuration file using OpenSSL.
<b>HTTP/HTTPS / FTP/FTPS User Name</b>	Enters user name to authenticate with HTTP/HTTPS FTP/FTPS server.
<b>HTTP/HTTPS / FTP/FTPS Password</b>	Enters password to authenticate with HTTP/HTTPS FTP/FTPS server.
<b>Firmware File Prefix</b>	Checks if firmware file is with matching prefix before downloading it. This field enables user to store different versions of firmware files in one directory on the firmware server.
<b>Firmware File Postfix</b>	Checks if firmware file is with matching postfix before downloading it. This field enables user to store different versions of firmware files in one directory on the firmware server.
<b>Config File Prefix</b>	Checks if configuration files are with matching prefix before downloading them. It allows user to store different configuration files in one directory on the provisioning server.
<b>Config File Postfix</b>	Checks if configuration files are with matching postfix before downloading them. It allows user to store different configuration files in one directory on the provisioning server.
<b>Allow DHCP Option 66 to Override Server</b>	Obtains configuration and upgrade server's information using options 66 from DHCP server. <b>Note:</b> If DHCP Option 66 is enabled, the HT812/HT814 will attempt downloading the firmware file from the server URL provided by DHCP, even though <b>Config Server Path</b> is left blank. The server URL provided by DHCP can include authentication credentials using following format: " <i>username:password@Provisioning_Server_IP</i> ".
<b>3CX Auto Provision</b>	Sends multicast "SUBSCRIBE" message for provisioning at booting stage, used for PnP (Plug-and-Play) configuration. Default is <b>Yes</b> .
<b>Automatic Upgrade</b>	Specifies when the firmware upgrade process will be initiated; there are 4 options: <ul style="list-style-type: none"> <li>• <b>No:</b> The HT812/HT814 will only do upgrade once at boot up.</li> <li>• <b>Check every X minute:</b> User needs to specify a period in minutes.</li> <li>• <b>Check every day:</b> User needs to specify "Hour of the day (0-23)".</li> <li>• <b>Check every week:</b> User needs to specify "Hour of the day (0-23)".</li> </ul>



	and “Day of the week (0-6)”. (Day of week is starting from Sunday). Default is <b>No</b> .
<b>Randomized Automatic Upgrade</b>	Randomized Automatic Upgrade within the range of hours of the day or postpone the upgrade every X minute(s) by random 1 to X minute(s).
<b>Always Check for New Firmware at Boot up</b>	Configures the HT812/HT814 to always search for the new firmware at boot up. During the boot stage, the HT812/HT814 will contact the firmware upgrade server to search for a new firmware, when available it will start the upgrade process, otherwise it will boot normally.
<b>Check New Firmware only when F/W pre/suffix changes</b>	Configure the HT812/HT814 to search for the new firmware when the firmware prefix / suffix changes. When this option is selected, the HT812/HT814 will check for updates only when the pre/suffix has been changed.
<b>Always Skip the Firmware Check</b>	Configures the HT812/HT814 to skip the firmware check when this option is selected the HT812/HT814 will always skip searching for a new firmware.
<b>Disable SIP NOTIFY Authentication</b>	Disables the SIP NOTIFY Authentication on the ATA adapter. If set to “Yes”, the ATA adapter will not challenge NOTIFY with 401. Default is <b>No</b>
<b>Authenticate Conf File</b>	Authenticates configuration before being accepted. This protects the configuration from unauthorized modifications. Default is <b>No</b> .
<b>Validate Server Certificates</b>	This feature allows users to validate server certificates with our trusted list of TLS connections. Default is enabled. The device needs to reboot after changing the setting.
<b>Trusted CA Certificates (A,B)</b>	Uses the certificate for Authentication if “Check Domain Certificates” is set to “Yes” under “Account” → “SIP Settings”.
<b>Load CA Certificate</b>	This feature allows user to specify which CA certificate to trust when performing server authentication.
<b>SIP TLS Certificate</b>	Specifies SSL certificate used for SIP over TLS is in X.509 format. The HT812/HT814 has built-in private key and SSL certificate. Maximum supported length is 4069.
<b>SIP TLS Private Key</b>	Specifies TLS private key used for SIP over TLS is in X.509 format. Maximum supported length is 4069.
<b>SIP TLS Private Key Password</b>	Specifies SSL Private key password used for SIP Transport in TLS/TCP.





<b>Custom Certificate (Private Key + Certificate)</b>	Allows users to update to the device their own certificate signed by custom CA certificate to manage client authentication.
<b>Enable TR-069</b>	Sets the ATA adapter system to enable the “CPE WAN Management Protocol” (TR-069). Default setting is <b>Yes</b> .
<b>ACS URL</b>	Specifies URL of TR-069 Auto Configuration Servers (e.g., http://acs.mycompany.com), or IP address. Default setting is: “https://acs.gdms.cloud”
<b>ACS Username</b>	Enters username to authenticate to ACS.
<b>ACS Password</b>	Enters password to authenticate to ACS.
<b>Periodic Inform Enable</b>	Sends periodic inform packets to ACS. Default is <b>Yes</b> .
<b>Periodic Inform Interval</b>	Sets frequency that the inform packets will be sent out to ACS. Default is 86400 seconds.
<b>Connection Request Username</b>	Enters username for ACS to connect to the HT812/HT814.
<b>Connection Request Password</b>	Enters password for ACS to connect to the HT812/HT814.
<b>Connection Request Port</b>	This feature allows user to configure the TR-069 connection request port.
<b>CPE SSL Certificate</b>	Configures the Cert File for the ATA to connect to the ACS via SSL.
<b>CPE SSL Private Key</b>	Specifies the Cert Key for the ATA to connect to the ACS via SSL.
<b>Enable SNMP</b>	Default is <b>No</b> .
<b>SNMP Version</b>	Choose between (Version 1, Version 2c, or Version 3).
<b>SNMP Port</b>	Listening Port of SNMP daemon (Default 161).
<b>SNMP Trap IP Address</b>	IP address of trap destination. Up to 3 trap destinations are supported. Users should enter the IP addresses separated with comma (,).
<b>Port of Trap port</b>	Port of Trap destination (Default 162)



<b>SNMP Trap Version</b>	Choose between (Version 1, Version 2c, or Version 3).
<b>SNMP Trap Interval</b>	Time interval between traps (Default is 5).
<b>SNMPv1/v2c Community</b>	Name of SNMPv1/v2c community.
<b>SNMPv1/v2c Trap Community</b>	Name of SNMPv1/v2c trap community.
<b>SNMPv3 User Name</b>	User name for SNMPv3.
<b>SNMPv3 Security Level</b>	<p><b>noAuthUser:</b> Users with security level noAuthnoPriv and context name as noAuth.</p> <p><b>authUser:</b> Users with security level authNoPriv and context name as auth.</p> <p><b>privUser :</b> Users with security level authPriv and context name as priv.</p>
<b>SNMPv3 Authentication Protocol</b>	Select the Authentication Protocol: “None” or “MD5” or “SHA.”
<b>SNMPv3 Privacy Protocol</b>	Select the Privacy Protocol: “None” or “AES/AES128” or “DES”.
<b>SNMPv3 Authentication Key</b>	Enter the Authentication Key.
<b>SNMPv3 Privacy Key</b>	Enter the Privacy Key.
<b>SNMPv3 Trap User Name</b>	User name for SNMPv3 Trap.
<b>SNMPv3 Trap Security Level</b>	<ul style="list-style-type: none"> <li>• <b>noAuthUser:</b> Users with security level noAuthnoPriv and context name as noAuth.</li> <li>• <b>authUser:</b> Users with security level authNoPriv and context name as auth.</li> <li>• <b>privUser:</b> Users with security level authPriv and context name as priv.</li> </ul>
<b>SNMPv3 Trap Authentication Protocol</b>	Select the Authentication Protocol: “None” or “MD5” or “SHA”.
<b>SNMPv3 Trap Privacy Protocol</b>	Select the Privacy Protocol: “None” or “AES/AES128” or “DES”.
<b>SNMPv3 Trap Authentication Key</b>	Enter the Trap Authentication Key.

<b>SNMPv3 Trap Privacy Key</b>	Enter the Trap Privacy Key.
<b>Enable RADIUS Web Access Control</b>	Default is <b>No</b> .
<b>Action upon RADIUS Auth Server Error</b>	Choose action upon RADIUS server error. Default is Authenticate Locally (Default Authenticate Locally)
<b>RADIUS Auth Server Address</b>	Address of RADIUS Auth server.
<b>RADIUS Auth Server Port</b>	Port of RADIUS Auth server.
<b>RADIUS Shared Secret</b>	Set RADIUS shared secret.
<b>RADIUS VSA Vendor ID</b>	Configure RADIUS VSA Vendor ID to match RADIUS server's configuration. Default is 42397 for Grandstream Networks Inc.
<b>RADIUS VSA Access Level Attribute</b>	Configure RADIUS VSA Access Level Attribute to match RADIUS server's configuration. Incorrect setting would cause Radius authenticate fail.
<b>Enable DDNS</b>	Allow users to use DDNS.
<b>DDNS Server</b>	Selects DDNS Server: dyndns, freedns.afraid.org, zoneedit.com, no-ip.com, oray.net. Default is dyndns.
<b>DDNS Username</b>	64 characters as Max String Length.
<b>DDNS Password</b>	64 characters as Max String Length.
<b>DDNS Hostname</b>	64 characters as Max String Length.
<b>DDNS Hash</b>	64 characters as Max String Length.
<b>Enable OpenVPN</b>	Allow user to enable OpenVPN. Default is No.
<b>OpenVPN Server Address</b>	Specify the IP address or FQDN for the OpenVPN Server.
<b>OpenVPN Port</b>	Specify the listening port of the OpenVPN server. Default is 1194.
<b>OpenVPN Interface type</b>	Specify the Interface type of OpenVPN whether TAP or TUN. Default is TUN.
<b>OpenVPN Transport</b>	Specify the Transport Type of OpenVPN whether UDP or TCP. Default is UDP.



<b>Enable OpenVPN LZO Compression</b>	Enable OpenVPN LZO Compression. Default is Yes.
<b>OpenVPN Encryption</b>	Select the OpenVPN Encryption. Default is BF-CBC 128 bit (default key).
<b>OpenVPN Digest</b>	Select the OpenVPN Digest. Default is SHA1.
<b>OpenVPN Username</b>	Allows users to configure OpenVPN username
<b>OpenVPN Password</b>	Allows users to configure OpenVPN Password
<b>OpenVPN CA</b>	Specifies the OpenVPN CA. Maximum Character Number is 8192.
<b>OpenVPN Certificate</b>	Specifies the OpenVPN Certificate. Maximum Character Number is 8192.
<b>OpenVPN Client Key</b>	Specifies the Client Key. Maximum Character Number is 8192.
<b>OpenVPN Client Key Password</b>	Configures the OpenVPN Client Key Password. Maximum Length is 64.
<b>System Ring Cadence</b>	Sets ring cadences for all incoming calls. Syntax: c=on1/off1-on2/off2-on3/off3;) Default is set to c=2000/4000; (US standards) on1 is the period of ringing ("On time" in "ms") while off1 is the period of silence. Up to three cadences are supported.
<b>Call Progress Tones</b> <ul style="list-style-type: none"> <li>• <b>Dial tone</b></li> <li>• <b>Ring back tone</b></li> <li>• <b>Busy tone</b></li> <li>• <b>Reorder tone</b></li> <li>• <b>Confirmation tone</b></li> <li>• <b>Call-Waiting tone</b></li> <li>• <b>Prompt Tone</b></li> <li>• <b>Conference Party Hang-up Tone*</b></li> <li>• <b>Special Proceed Indication Tone</b></li> </ul>	<p>Configures tone frequencies according to user preference. By default, the tones are set to North American frequencies. Frequencies should be configured with known values to avoid uncomfortable high pitch sounds. ON is the period of ringing (ON time in ms) while OFF is the period of silence. In order to set a continuous ring, OFF should be zero. Otherwise, it will ring ON ms and a pause of OFF ms and then repeats the pattern.</p> <p>Please refer to the document below to determine your local call progress tones:  <a href="http://www.itu.int/ITU-T/inr/forms/files/tones-0203.pdf">http://www.itu.int/ITU-T/inr/forms/files/tones-0203.pdf</a></p> <p>* "Conference Party Hang-up Tone" will apply only if the "Special Feature" is set to "MTS".</p> <p>Special Proceed Indication Tone: This feature allows user to configure the tone played when user goes offhook and there is voicemail on the subscribed mailbox. Need to set 'MWI Tone' to 'Special Proceed Indication Tone' to use this feature.</p>



<b>Prompt Tone Access Code</b>	Specifies the key pattern to get Prompt Tone. Maximum 20 digits
<b>Lock Keypad Update</b>	Locks configuration update via keypad. Default is <b>No</b> .
<b>Disable Voice Prompt</b>	Removes ability to use integrated voice prompt menu configuration. Default is <b>No</b> .
<b>Disable Direct IP Call</b>	Deactivates Direct IP-to-IP calling function. Default is <b>No</b> .
<b>Play Busy Tone When Account is unregistered</b>	When this feature is set to Yes, device will play busy tone when the FXS port account is not registered, and the attached analog phone is off hook. <b>Note:</b> When this feature is enabled, “Outgoing Call without Registration” option need to be set to <b>NO</b> as well for the busy tone to be played instead of the dial tone when the handset is placed off hook and the account is unregistered.
<b>Blacklist for Incoming Calls</b>	Allow users to block incoming calls from specific list of numbers. Maximum allow 10 SIP numbers and each number should be separated by a comma (’,’) in web UI. Other allowed characters: 26 letters (A-Z and a-z), comma (“,”), asterisk (“*”), pound sign (“#”) and plus sign (“+”).
<b>NTP Server</b>	Defines URL or IP address of the NTP (Network Time Protocol). Used by the HT818 to synchronize the date and time. Public NTP servers can be found at <a href="http://www.ntp.org">http://www.ntp.org</a> . Default is <b>pool.ntp.org</b>
<b>Allow DHCP Option 42 to NTP Server</b>	Obtains NTP server address from a DHCP server using DHCP Option 42; it will override configured NTP Server. If set to “No”, the HT818 will use configured NTP server to synchronize time and date even if a NTP server is provided by DHCP server. Default is <b>Yes</b> .
<b>DHCP Option 17 Enterprise Number</b>	This option contains vendor-specific option data, much like DHCPv4 option 43. There is an extra difference in that in DHCPv6, this option carries a vendor ID as well, which allows for data from multiple vendors to be provided to the device. Default is <b>3561</b> .
<b>CDR File Option</b>	By default, the device will split the allowed memory for CDR file into 2 parts. Device will create the first CDR file which is half of the allowed size, when it is full, device will create the second file. <ul style="list-style-type: none"> <li>• When “CDR File Option” is set to Default “<b>Keep</b>”, device will keep the call records when both files are full, no more new record will be stored.</li> <li>• When this feature is set to “<b>Override</b>”, device will clear the first CDR</li> </ul>



	<p>file and start storing again.</p> <p>The CDR file output will be available at Status page: [CDR File]</p>
<b>SIP File Option</b>	<p>By default, the device will split the allowed memory for SIP file into 2 parts. Device will create the first SIP file which is half of the allowed size, when it is full, device will create the second file.</p> <ul style="list-style-type: none"> <li>• When “SIP File Option” is set to Default “<b>Keep</b>”, device will keep the call records when both files are full, no more new record will be stored.</li> <li>• When this feature is set to “<b>Override</b>”, device will clear the first SIP file and start storing again.</li> </ul> <p>The SIP file output will be available at Status page: [SIP File]</p> <p><b>Note:</b> “<b>Send SIP Log</b>” must be enabled to be able to capture the trace.</p>
<b>Disable Weak TLS Cipher Suites</b>	<p>Allows users to disable weak ciphers DES/3DES and RC4, Symmetric Encryption SEED, Symmetric Authentication MD5, Protocol Version SSLv2/SSLv3 or Disable All of The Above Weak TLS Ciphers Suites.</p> <p>Default is <b>No</b>.</p>
<b>Minimum TLS Version</b>	<p>The Feature allows users to choose the Minimum TLS Version. Choices are:</p> <ul style="list-style-type: none"> <li>○ Unlimited.</li> <li>○ TLS 1.0.</li> <li>○ TLS 1.1.</li> <li>○ TLS 1.2.</li> </ul> <p>Default is <b>Unlimited</b>.</p>
<b>Maximum TLS Version</b>	<p>The Feature allows users to choose the Maximum TLS Version. Choices are:</p> <ul style="list-style-type: none"> <li>○ Unlimited.</li> <li>○ TLS 1.0.</li> <li>○ TLS 1.1.</li> <li>○ TLS 1.2.</li> </ul> <p>Default is <b>Unlimited</b>.</p>
<b>Syslog Protocol</b>	<p>If set to SSL/TLS, the syslog messages will be sent through secured TLS protocol to syslog server. Default setting is <b>UDP</b>.</p> <p><b>Notes:</b> The CA certificate is required to connect with the TLS server. A reboot is required to take effect.</p>
<b>Syslog Server</b>	<p>URL or IP address of syslog server.</p>



	<p><b>Note:</b> A reboot is required to take effect.</p>
<b>Syslog Level</b>	<p>Select the HT81x to report the log level. Default is NONE. The level is one of EXTRA DEBUG, DEBUG, INFO, WARNING or ERROR. Syslog messages are sent based on the following events:</p> <ol style="list-style-type: none"> <li>1. product model/version on boot up (INFO level)</li> <li>2. NAT related info (INFO level)</li> <li>3. sent or received SIP message (DEBUG level)</li> <li>4. SIP message summary (INFO level)</li> <li>5. inbound and outbound calls (INFO level)</li> <li>6. registration status change (INFO level)</li> <li>7. negotiated codec (INFO level)</li> <li>8. Ethernet link up (INFO level)</li> <li>9. SLIC chip exception (WARNING and ERROR levels)</li> <li>10. memory exception (ERROR level)</li> <li>11. extra syslog style (EXTRA DEBUG level)</li> </ol> <p><b>Note:</b> A reboot is required to take effect.</p>
<b>Send SIP Log</b>	<p>Configures whether the SIP log will be included in the syslog messages. The default setting is <b>No</b>.</p> <p><b>Note:</b> A reboot is required to take effect.</p>
<b>Always Send HTTP Basic Authentication Information</b>	<p>If set to Yes, the device will send configured user name and password within HTTP request without server sending authentication challenge.</p>
<b>Automatic Reboot</b>	<p>Default is <b>No</b>. When “Yes, reboot every day at hour” or “Yes, reboot every week at day” or “Yes, reboot every month at day” is checked, user can specify “Hour of the day (0-23)” or “Day of the week (0-6)” or “Day of the month (0-30)”. Default time is Monday 1AM.</p>
<b>Download Device Configuration</b>	<p>Press <b>Download</b> button to download device configuration file to local computer. The filename is “config.txt”. The file is plain text and not including password fields.</p>
<b>Download Device XML Configuration</b>	<p>Press <b>Download</b> button to download device configuration file to local computer. The filename is “config.xml”. The file will not include password fields.</p>



<b>Upload Firmware</b>	Press <b>Upload from local directory</b> button to load the firmware file to the device from your computer. The firmware filename should be “ht81xfw.bin”.
<b>Upload Configuration</b>	Press <b>Upload from local directory</b> button to load configuration file to the device from your computer. The configuration file should be an XML file (for instance: “config.xml”). Note: The field <mac> is not mandatory in the document but if available only device with specified MAC address will accept the configuration file.
<b>Export Backup Configuration</b>	Press <b>Download</b> button to export device backup configuration to computer. The output is “cfg<mac>_enc.xml” (where <mac> is the MAC address of the device). The file is encrypted and can be used on same device only.
<b>Restore From Backup Configuration</b>	Press <b>Upload</b> button to restore device configuration from previously exported backup configuration.

## Profiles Pages Definitions

Table 9: Profiles Pages

Profiles (1,2)	
<b>Profile Active</b>	Activates / Deactivates the accounts. The FXS port configuration will not change if disabled, although the port will not be operational, in this state, there will be no dial tone when picking up the analog phone and making/receiving calls will not be possible.
<b>Primary SIP Server</b>	Configures SIP server IP address (Supports both IPv4 and IPv6 addresses) or domain name provided by VoIP service provider. (For example: sip.mycompany.com, IPv4:192.168.5.170, or IPv6: fe80::20b:82ff:fe75:211d). This is the primary SIP server used to send/receive SIP messages from/to HT812/HT814.
<b>Failover SIP Server</b>	Defines failover SIP server IP address (Supports both IPv4 and IPv6 addresses) or domain name provided by VoIP service provider. (For example: sip.mycompany.com, IPv4:192.168.5.170, or IPv6 fe80::20b:82ff:fe75:211d:). This server will be used if primary SIP server becomes unavailable.
<b>Prefer Primary SIP Server</b>	Selects to prefer primary SIP server. The account will register to primary Server if registration with Failover server expires. Default is <b>No</b> .
<b>Outbound Proxy</b>	Specifies IP address (Supports both IPv4 and IPv6 addresses) or domain name of outbound Proxy, or media gateway, or session border controller. (For





	<p>example: proxy.myprovider.com, IPv4: 192.168.5.170, or IPv6: fe80::20b:82ff:fe75:211d). It's Used by HT818 for firewall or NAT penetration in different network environments. If symmetric NAT is detected, STUN will not work, and only outbound proxy can correct the problem</p>
<b>Backup Outbound Proxy</b>	<p>Configures the backup outbound proxy to be used when the "Outbound Proxy" registration fails. (For example: proxy.myprovider.com, or IP address, if any: IPv4: 192.168.5.170/ IPv6: fe80::20b:82ff:fe75:211d). By default, this field is left empty.</p>
<b>Prefer Primary Outbound Proxy</b>	<p>If the user configures this option to "Yes", when registration expires, the device will re-register via primary outbound proxy. By default, this option is disabled.</p>
<b>Allow DHCP Option 120 (override SIP Server)</b>	<p>Configures the HT812/HT814 to collect SIP server address from DHCP option 120. Default is <b>No</b>.</p>
<b>SIP transport</b>	<p>Selects transport protocol for SIP packets; UDP or TCP or TLS. Please make sure your SIP Server or network environment supports SIP over the selected transport method. Default is <b>UDP</b>.</p>
<b>SIP URI Scheme When Using TLS</b>	<p>Specifies if "sip" or "sips" will be used when TLS/TCP is selected for SIP Transport. The default setting is "sips".</p>
<b>Use Actual Ephemeral Port in Contact with TCP/TLS</b>	<p>Controls the port information in the Via header and Contact header. If set to "No", these port numbers will use the permanent listening port on the phone. Otherwise, they will use the ephemeral port for the connection. Default is <b>No</b>.</p>
<b>NAT Traversal</b>	<p>Indicates type of NAT for each account. This parameter configures whether the NAT traversal mechanism is activated. Users could select the mechanism from No, Keep-alive, STUN, UPnP. Default setting is <b>No</b>.</p>
<b>DNS Mode</b>	<p>Selects DNS mode to use for the client to look up server. One mode can be chosen.</p> <ul style="list-style-type: none"> <li>• <b>A Record (Default):</b> resolves IP Address of target according to domain name.</li> <li>• <b>SRV:</b> DNS SRV resource records indicate how to find services for various protocols.</li> <li>• <b>NAPTR/SRV:</b> Naming Authority Pointer according to RFC 2915.</li> <li>• <b>Use Configured IP:</b> If the SIP server is configured as domain name, device will not send DNS queries, but will use "Primary IP" or "Backup</li> </ul>



	<p>IP" to send SIP message if at least one of them is not empty. It will try to use "Primary IP" first, after 3 tries without any response, it will switch to "Backup IP 1", then "Backup IP 2", and then it will switch back to "Primary IP" after 3 retries.</p>
<b>DNS SRV use Registered IP</b>	<p>When the HT81x is registered using the second SRV record, making an outbound call, it will try the second SRV (registered IP) first. By default, this option is disabled, and the DNS SRV will use first SRV instead of the registered IP.</p>
<b>DNS SRV Failover Mode</b>	<p>Configure the preferred IP mode when DNS Mode is SRV or NAPTR/SRV.</p> <ul style="list-style-type: none"> <li>• Default SIP request will always be sent to the address with the top priority based on the SRV query result, even if this address is different from the registered IP address.</li> <li>• Saved one until DNS TTL SIP request will always be sent to the registered IP address until DNS TTL expires or registered IP address is unreachable</li> <li>• Saved on until no response SIP request will always be sent to the registered IP address only until registered IP address is unreachable.</li> </ul>
<b>Failback Timer</b>	<p>When the primary SBC is up, device will send SIP requests to the primary SBC. If at any point device fails over to the secondary SBC, the SIP requests will stay on the failover SBC for the duration of the failback timer. When the timer expires, device will send SIP requests to the primary SBC, (in minutes. Default is 60 minutes, max 45 days).</p>
<b>Register before DNS SRV Failover</b>	<p>This feature is used to control whether the device need to initiate a new registration request (following existing DNS SRV fail-over mode) first and then direct the non-registration SIP request (INVITE) to the new successfully registered server or not.</p>
<b>TEL URI</b>	<p>Indicates E.164 number in "From" header by adding "User=Phone" parameter or using "Tel:" in SIP packets, if the HT812/HT814 has an assigned PSTN Number.</p> <ul style="list-style-type: none"> <li>• <b>Disabled:</b> Use "SIP User ID" information in the Request-Line and "From" header.</li> <li>• <b>User=Phone:</b> "User=Phone" parameter will be attached to the Request-Line and "From" header in the SIP request to indicate the E.164 number. If set to "Enable".</li> <li>• <b>Enabled:</b> "Tel:" will be used instead of "sip:" in the SIP request.</li> </ul>



	Please consult your carrier before changing this parameter. Default is <b>Disabled</b> .
<b>Use Request Routing ID in SIP INVITE Header</b>	If set to Yes, device will use the configured [ <b>Request URI Routing ID</b> ] in the SIP INVITE. This option is usually used under a SIP trunk account's configuration. Default is <b>No</b> .
<b>SIP Registration</b>	Controls whether the HT812/HT814 needs to send REGISTER messages to the proxy server. Default setting is <b>Yes</b> .
<b>Unregister on Reboot</b>	Controls whether to clear SIP user's information by sending un-register request to the proxy server. The un-registration is performed by sending a REGISTER message with Contact set to * and Expires=0 parameters to the SIP server. This will unregister the SIP account under the concerned FXS page. Default is <b>No</b> .
<b>Outgoing Call Without Registration</b>	Enables the ability to place outgoing calls even if the account is not registered (if allowed by ITSP); device will not be able to receive incoming calls. Default is <b>No</b> .
<b>Register Expiration</b>	Refreshes registration periodically with specified SIP proxy (in minutes). Maximum interval is 65535 minutes (about 45 days). Default is <b>60</b> minutes (or 1 hour).
<b>Reregister Before Expiration</b>	Sends re-register request after specific time (in seconds) to renew registration before the previous registration expires.
<b>SIP Registration Failure Retry Wait Time</b>	Sends re-register request after specific time (in seconds) when registration process fails. Maximum interval is 3600 seconds (1 hour). Default is <b>20</b> seconds.
<b>SIP Registration Failure Retry Wait Time upon 403 Forbidden</b>	Sends re-register request after specific time (in seconds) when registration process fails with error 403 Forbidden. Maximum interval is 3600 seconds (1 hour). Default is <b>1200</b> seconds.
<b>MWI Tone</b>	When set to Default, device will play Stutter Dial Tone when there is voicemail, if set to Special Proceed Indication Tone, device will play the configured special proceed indication tone upon user offhook when there is voicemail
<b>Enable SIP OPTIONS/NOTIFY Keep Alive</b>	Enables SIP OPTIONS or SIP NOTIFY to track account registration status so the ATA will send periodic OPTIONS/NOTIFY message to server to track the connection status with the server. Default setting is <b>No</b> .



<b>SIP OPTIONS/NOTIFY Keep Alive Interval</b>	Configures the time interval when the ATA send OPTIONS or NOTIFY message to SIP server. The default setting is 30 seconds, which means the ATA will send an OPTIONS/NOTIFY message to the server every 30 seconds. The default range is <b>1-64800</b> .
<b>SIP OPTIONS Keep Alive Max Lost</b>	Defines the Number of max lost packets for SIP OPTIONS Keep Alive before re-registration. Between 3-10, default is <b>3</b> .
<b>Layer 3 QoS</b>	Defines Diff-Serv values for SIP and RTP. SIP DSCP (Diff-Serv value in decimal, 0-63, default <b>26</b> ) RTP DSCP (Diff-Serv value in decimal, 0-63, default <b>46</b> )
<b>Local SIP Port</b>	Defines local port to use by the HT812/HT814 for listening and transmitting SIP packets. Default value for FXS 1 is 5060 and 5062 for FXS 2.
<b>Local RTP Port</b>	Defines the local RTP-RTCP port pair the HT812/HT814 will listen and transmit. It is the HT812/HT814 RTP port for channel 0. The default value for FXS port is <b>5004</b>
<b>Use Random SIP Port</b>	Controls whether to use configured or random SIP ports. This is usually necessary when multiple HT812/HT814 are behind the same NAT. Default is <b>No</b> .
<b>Use Random RTP Port</b>	Controls whether to use configured or random RTP ports. This is usually necessary when multiple HT812/HT814 are behind the same NAT. Default is <b>No</b> .
<b>Enable RTCP</b>	Allows users to enable RTCP. The default setting is "Yes".
<b>Hold Target Before Refer</b>	Allows user to hold or not hold the phone call before referring. The default setting is <b>Yes</b> .
<b>Refer-To Use Target Contact</b>	Includes target's "Contact" header information in "Refer-To" header when using attended transfer. Default is <b>No</b> .
<b>Transfer on Conference Hang-up</b>	If set to "Yes", when the phone hangs up as the conference initiator, the conference call will be transferred to the other parties so that other parties will remain in the conference call. Default setting is <b>No</b> .
<b>Disable Bellcore Style 3-Way Conference</b>	Gives the users the possibility of making conference calls by pressing "Flash" key, when it's enabled by dialing *23 +second callee number. Default is <b>No</b>
<b>Remove OBP from Route Header</b>	Removes outbound proxy info in "Route" header when sending SIP packets. Default is <b>No</b> .



<b>Support SIP Instance ID</b>	Includes "SIP Instance ID" attribute to "Contact" header in REGISTER request as defined in IETF SIP outbound draft. Default is <b>No</b> .
<b>Validate Incoming SIP Messages</b>	Validates incoming SIP messages. Default is <b>No</b> .
<b>Check SIP User ID for Incoming INVITE</b>	Checks SIP User ID in the Request URI of incoming INVITE; if it doesn't match the HT812/HT814 SIP User ID, the call will be rejected. Direct IP calling will also be disabled. Default is <b>No</b> .
<b>Authenticate Incoming INVITE</b>	Challenges the incoming INVITE for authentication with SIP 401 Unauthorized message. Default is <b>No</b> .
<b>Authenticate Server Certificate Domain</b>	Configures whether to validate the domain certificate when download the firmware/config file. If it is set to "Yes", the phone will download the firmware/config file only from the legitimate server. The default setting is "No".
<b>Authenticate server certificate chain</b>	Configures whether to validate the server certificate when download the firmware/config file. If it is set to "Yes", the phone will download the firmware/config file only from the legitimate server. The default setting is "No".
<b>Allow Incoming SIP Messages from SIP Proxy Only</b>	Checks SIP address of the Request URI in the incoming SIP message; if it doesn't match the SIP server address of the account, the call will be rejected. Default is <b>No</b> .
<b>Use Privacy Header</b>	Determines if the "Privacy header" will be presented in the SIP INVITE message and if it includes the caller info in this header. If set to Default, it will add Privacy header unless special feature is <b>Telkom SA</b> or <b>CBCOM</b> . Default is <b>Default</b> .
<b>Use P-Preferred-Identity Header</b>	Specifies if the P-Preferred-Identity Header will be presented in the SIP INVITE message. If set to "default", the P-Preferred-Identity Header will be omitted in SIP INVITE message when <b>Telkom SA</b> or <b>CBCOM</b> is active. If set to "Yes", the P-Preferred- Identity Header will always be presented. If set to "No", it will be omitted. Default setting is: <b>Default</b> .
<b>Use P-Access-Network-Info Header</b>	With this feature enabled, device will populate the WAN access node with IEE-802.11a, IEE-802.11b in P-Access-Network-Info SIP header.
<b>Use P-Emergency-Info Header</b>	This feature support of IEEE-48-addr and IEEE-EUI-64 in SIP header for emergency calls.



<b>Use P-Asserted-Identity Header</b>	<p>When this feature is set to Yes, device will send P-Asserted-Identity Header on the SIP Invite.</p> <p>Default setting is No.</p>
<b>SIP REGISTER Contact Header Uses</b>	<p>Specifies which address (LAN or WAN address) the device will detect to use it in SIP Register Contact Header.</p> <p>Default is <b>LAN Address</b>.</p>
<b>Caller ID Fetch Order</b>	<p>Selects the Caller ID display order which need to be respected by the ATA.</p> <p>The available options are:</p> <ul style="list-style-type: none"> <li>● <b>Auto</b>: When set to “Auto”, the ATA will look for the caller ID in the order of P-Asserted Identity Header, Remote-Party-ID Header and From Header in the incoming SIP INVITE.</li> <li>● <b>Disabled</b>: When set to "Disabled", all incoming calls are displayed with "Unavailable".</li> <li>● <b>From Header</b>: When set to “From Header”, the ATA will use the FROM header to display the caller ID.</li> </ul>
<b>Allow SIP Factory Reset</b>	<p>Allows to reset the devices directly through SIP Notify. If “Allow SIP Factory Reset” is set to “YES” under FXS PORT, then the ATA receives the NOTIFY from the SIP server with <b>Event: reset</b>, the HT should perform a factory reset after the authentication.</p> <p>The authentication in this case can be either with:</p> <ul style="list-style-type: none"> <li>● The admin password if no SIP account is configured on the HT.</li> <li>● With the credentials of the SIP account if configured on the ATA.</li> </ul>
<b>Maximum Number of SIP Request Retries</b>	<p>This feature allows user to configure the number of SIP retries before failover occurs. (between 1 and 10, default is 4).</p>
<b>SIP T1 Timeout</b>	<p>Defines T1 timeout value. It is an estimate of the round-trip time between the client and server transactions. For example, the HT812/HT814 will attempt to send a request to a SIP server. The time it takes between sending out the request to the point of getting a response is the SIP T1 timer. If no response is received the timeout is increased to (2*T1) and then (4*T1). Request re-transmit retries would continue until a maximum amount of time defined by T2. Default is <b>0.5</b> seconds.</p>



<b>SIP T2 Interval</b>	Identifies maximum retransmission interval for non-INVITE requests and INVITE responses. Retransmitting and doubling of T1 continues until it reaches T2 value. Default is <b>4</b> seconds.
<b>SIP Timer D</b>	Configures SIP Timer D defined in RFC3261. 0 - 64 seconds. Default is <b>0</b> .
<b>DTMF Payload Type</b>	Defines payload type for DTMF using RFC2833.
<b>Preferred DTMF method (in order)</b>	Sorts DTMF methods (in-audio, via RTP (RFC2833) or via SIP INFO) by priority.
<b>Inband DTMF Duration</b>	Allows to adjust the inband DTMF duration sent from ATA to IPPBX. Default is <b>100</b> ms. Valid range: 40-2000 ms. Inter-duration: 50 ms. Valid range: 40-2000 ms.
<b>Disable DTMF Negotiation</b>	Uses above DTMF order without negotiation. Default is <b>No</b> .
<b>Generate Continuous RFC2833 Events</b>	When enabled the RFC2833 events are generated until key is released. Default is <b>No</b> .
<b>Send Hook Flash Event</b>	Default is <b>No</b> . If set to yes, flash will be sent as DTMF event.
<b>Flash Digit Control</b>	When it set to YES it allows the user to perform some call setting when both channels are used while pressing: <ul style="list-style-type: none"> <li>• <b>"Flash + 1"</b> in order to hang up the current call and resume a call that was held.</li> <li>• <b>"Flash + 2"</b> in order to hold the current call and resume a call that was held.</li> <li>• <b>"Flash + 3"</b> in order to perform 3-way conference.</li> <li>• <b>"Flash + 4"</b> in order to perform attended transfer.</li> </ul> <b>Note:</b> Please refer to the user guide for detailed steps to perform above operations.
<b>Enable Call Waiting alert-info In 180 Ringing Response</b>	When set to Yes, Alert-Info header will be added in 180 Ringing for Call Waiting case
<b>Callee Flash to 3WC</b>	When this feature is set to <b>Yes</b> , device would be able to set up the 3 way conference call even when device is the callee in the second call. Default is <b>No</b> .
<b>Off Hook Auto Dial Delay</b>	Specifies the auto-dial delay after off hook.
<b>Proxy-Require</b>	Determines a SIP Extension to notify the SIP server that the HT812/HT814 is behind a NAT/Firewall.





<b>Use NAT IP</b>	Defines NAT IP address used in SIP/SDP messages. It should only be used if required by ITSP.
<b>SIP User-Agent</b>	This feature allows users to configure SIP User Agent. If not configured, device will use the default User Agent header.
<b>SIP User-Agent Postfix</b>	Configures the SIP User-Agent Postfix
<b>RFC2543 Hold</b>	Toggles between RFC2543 hold and RFC3261 hold. RFC2543 hold allows to disable the hold music sent to the other side, in this case IP address (0.0.0.0) it will be sent in SDP instead of the IP address of the unit . RFC3261 (a line) will play the hold music to the other side.
<b>Disable Call Waiting</b>	Disables receiving a second incoming call when the line is engaged. Default is <b>No</b> .
<b>Disable Call Waiting Caller ID</b>	Disables displaying caller ID when receiving a second incoming call. Default is <b>No</b> .
<b>Disable Call Waiting Tone</b>	Disables playing call waiting tone during active call when receiving a second incoming call. The CWCID will still be displayed. Default is <b>No</b> .
<b>Disable Connected Line ID</b>	Disables displaying the number of the person answering the phone. Default is <b>No</b> .
<b>Disable Receiver Off Hook Tone</b>	Enables / disables the warning to alert that the phone has been left off-hook for an extended period of time. Default is <b>No</b> .
<b>Disable Reminder Ring for On-Hold Call</b>	Enables playing the reminder ring. Default is <b>No</b> .
<b>Disable Reminder Ring for DND</b>	This feature allows user to disable reminder ring when FXS port is on DND mode. Default is <b>No</b>
<b>Disable Visual MWI</b>	Disables use of visual message waiting indicator when there is an unread voicemail message. Default is <b>No</b> .
<b>Visual MWI Type</b>	Configures Visual WMI Type of signal sent to the analog phone to make it turn the lamp ON upon receiving a Voice mail. Check the phone's manual to find out what signal is supported, FSK (default) or Neon. <b>Note:</b> Some phones (depends on the model of the analog phone) when this feature is set to NEON it might auto ring (short beeps) when there is a voice





	mail available for that FXS port where it is connected.
<b>Do Not Escape '#' as %23 in SIP URI</b>	Replaces # by %23 in some special situations. Default is <b>No</b> .
<b>Disable Multiple m Line in SDP</b>	Sends only one m line in SDP, regardless of how many m fields are in the incoming SDP. Default is <b>No</b> .
<b>Ring Timeout</b>	Stops ringing when incoming call if not answered within a specific period of time. When set to <b>0</b> there will be no ringing timeout. Default is <b>60</b> seconds.
<b>Hunting Group Ring Timeout</b>	If call is not answered within this designated time period, the call will be forwarded to the next member of a Hunt Group. Default value is <b>20</b> seconds.
<b>Hunting Group Type</b>	Specifies Hunting Group Type, either "Linear" or "Circular". <ul style="list-style-type: none"> <li>• <b>Linear</b> style will sort the call to the lowest numbered available line, this is also called "serial hunting".</li> <li>• <b>Circular</b> style will distribute the calls "round-robin". If a call is assigned to line 1, the next call goes to 2 and the next to 3. The succession throughout each of the lines continues even if one of the previous lines becomes available. When the end of the hunt group is reached, the hunting starts over at the first line. Lines are skipped if they are still busy on a previous call. Default is Circular.</li> </ul>
<b>Delayed Call Forward Wait Time</b>	Forwards incoming call if not answered within a specific period of time when delayed call forward is activated locally (using *92 code). Default value is <b>20</b> seconds.
<b>No Key Entry Timeout</b>	Initiates the call within this time interval if no additional key entry during dialing stage. Default is <b>4</b> seconds.
<b>Early Dial</b>	Sends an early INVITE each time a key is pressed when a user dials a number. Otherwise, only one INVITE is sent after full number is dialed (user presses <b>Dial Key</b> or after "no key entry timeout" expires). This option should be used only if there is a SIP proxy is configured and supporting "484 Incomplete Address" responses. Otherwise, the call will likely be rejected by the proxy (with a 404 Not Found error). Default is <b>No</b> . <i><u>This feature is NOT designed to work with and should NOT be enabled for direct IP-to-IP calling.</u></i>
<b>Dial Plan Prefix</b>	Adds specified prefix to dialed number.



<b>Use # as Dial Key</b>	Treats “#” as the “Send” (or “Dial”) key. If set to “No”, this “#” key can be included as part of the dialed number. Default is <b>Yes</b> .
<b>Disable # as Redial Key</b>	Disables # to act as Redial key. If set to “Yes” and feature “Use # as Dial Key” set to Yes, the # key will act as dial key but not as redial key. Default is <b>No</b> .
<b>Dial Plan</b>	<p><b>Dial Plan Rules:</b></p> <ol style="list-style-type: none"> <li>1. Accept Digits: 1,2,3,4,5,6,7,8,9,0 , * , #, A,a,B,b,C,c,D,d</li> <li>2. Grammar:       <ul style="list-style-type: none"> <li>x - any digit from 0-9;</li> <li>a. <b>xx+</b> - at least 2 digits number;</li> <li>b. <b>xx</b> – exactly 2 digits number;</li> <li>c. <b>^</b> - exclude;</li> <li>d. <b>.</b> – wildcard, matches one or more characters</li> <li>e. <b>[3-5]</b> - any digit of 3, 4, or 5;</li> <li>f. <b>[147]</b> - any digit 1, 4, or 7;</li> <li>g. <b>&lt;2=011&gt;</b> - replace digit 2 with 011 when dialing</li> <li>h. <b>&lt;=1&gt;</b> - add a leading 1 to all numbers dialed, vice versa will remove a 1 from the number dialed</li> <li>i. <b> </b> - or</li> <li>j. Flag T when adding a “T” at the end of the dial plan, the phone will wait for 3 seconds before dialing out. This gives users more flexibility on their dial plan setup. E.g., with dial plan 1XXT, phone will wait for 3 seconds to let user dial more than just 3 digits if needed. Originally the phone will dial out immediately after dialing the third digit.</li> </ul> <ul style="list-style-type: none"> <li>• <b>Example 1:</b> {[369]11   1617xxxxxxx} – Allow 311, 611, 911, and any 10-digit numbers of leading digits 1617</li> <li>• <b>Example 2:</b> {^1900x+   &lt;=1617&gt;xxxxxxx} – Block any number with leading digits 1900 and add prefix 1617 for any dialed 7-digit numbers</li> <li>• <b>Example 3:</b> {1xxx[2-9]xxxxxx   &lt;2=011&gt;x+} – Allow any length of number with leading digit 2 and 10 digit-numbers of leading digit 1 and leading exchange number between 2 and 9; If leading digit is 2, replace leading digit 2 with 011 before dialing.</li> </ul> </li> <li>3. Default: Outgoing - { x+   \+x+   *x+   *xx*x+ }</li> </ol> <p><u>Example of a simple dial plan used in a Home/Office in the US:</u>  <b>{ ^1900x.   &lt;=1617&gt;[2-9]xxxxxx   1[2-9]xx[2-9]xxxxxx   011[2-9]x.   [3469]11 }</b></p>



	<p><b>Explanation</b> of example rule (reading from left to right):</p> <ul style="list-style-type: none"> <li>• <b>^1900x.</b> - prevents dialing any number started with 1900</li> <li>• <b>&lt;=1617&gt;[2-9]xxxxxx</b> - allows dialing to local area code (617) numbers by dialing 7 numbers and 1617 area code will be added automatically</li> <li>• <b>1[2-9]xx[2-9]xxxxxx</b> - allows dialing to any US/Canada Number with 11 digits length</li> <li>• <b>011[2-9]x.</b> - allows international calls starting with 011</li> <li>• <b>[3469]11</b> - allow dialing special and emergency numbers 311, 411, 611 and 911</li> </ul> <p><b>Note:</b> In some cases, user wishes to dial strings such as *123 to activate voice mail or other application provided by service provider. In this case * should be predefined inside dial plan feature. An example dial plan will be: { *x+ } which allows the user to dial * followed by any length of numbers.</p>
<b>SUBSCRIBE for MWI</b>	Sends SUBSCRIBE periodically (depends on “Register Expiration” parameter) for message waiting indication. Default is <b>No</b> .
<b>Send Anonymous</b>	Sets “From”, “Privacy” and “P_Asserted_Identity” headers in outgoing INVITE message to “anonymous”, blocking caller ID. Default is <b>No</b> .
<b>Anonymous Call Rejection</b>	Rejects incoming calls with anonymous caller ID with “486 Busy here” message. Default is <b>No</b> .
<b>Special Feature</b>	Selects Soft switch vendors’ special requirements Example of vendors: BroadSoft, CBCOM, RNK, Huawei, China Mobile, ZTE IMS, PhonePower, TELKOM SA, Vonage, Metaswitch, CenturyLink, MTS, Oi_BR, Telefonica. Default is <b>Standard</b> .
<b>Enable Session Timer</b>	Disable the session timer when this option is set to “No”. By default, this option is enabled.
<b>Session Expiration</b>	Enables SIP sessions to be periodically “refreshed” via a SIP request (UPDATE, or re-INVITE). When the session interval expires, if there is no refresh via an UPDATE or re-INVITE message, the session will be terminated. Session Expiration is the time (in seconds) at which the session is considered timed out if no successful session refresh transaction occurs beforehand. Valid range is 90-64800 seconds. Default is <b>180</b> seconds.
<b>Min-SE</b>	Defines Minimum session expiration (in seconds). Default is <b>90</b> seconds.
<b>Caller Request Timer</b>	Uses session timer when making outbound calls if remote party supports it. Valid range is 90-64800 seconds. Default is <b>No</b> .



<b>Callee Request Timer</b>	Uses session timer when receiving inbound calls with session timer request. Default is <b>No</b> .
<b>Force Timer</b>	Uses session timer even if the remote party does not support this feature. Selecting “No” will enable session timer only when the remote party supports it. To turn off Session Timer, select “No” for Caller and Callee Request Timer, and Force Timer. Default is <b>No</b> .
<b>UAC Specify Refresher</b>	Specifies which end will act as refresher for outgoing calls. <ul style="list-style-type: none"> <li>• Default is <b>Omit</b>.</li> <li>• <b>UAC</b>: The HandyTone acts as the refresher.</li> <li>• <b>UAS</b>: Callee or proxy server act as the refresher.</li> </ul>
<b>UAS Specify Refresher</b>	Specifies which end will act as refresher for incoming calls. Default is <b>Omit</b> .: <ul style="list-style-type: none"> <li>• <b>UAS</b>: The HandyTone acts as the refresher.</li> <li>• <b>UAC</b>: Callee or proxy server act as the refresher.</li> </ul>
<b>Force INVITE</b>	Uses INVITE message to refresh the session timer. Default is <b>No</b> .
<b>Enable 100rel</b>	Appends “100rel” attribute to the value of the required header of the initial signaling messages. Default is <b>No</b> .
<b>Add Auth Header on Initial REGISTER</b>	Adds “Authentication” header with blank “nonce” attribute in the initial SIP REGISTER request. Default is <b>No</b> .
<b>Conference URI</b>	Allows users to manually configure the conference URL. The default is null.
<b>Use First Matching Vocoder in 200OK SDP</b>	Includes only the first matching vocoder in its 200OK response, otherwise it will include all matching vocoders in same order received in INVITE. Default is <b>No</b> .
<b>Preferred Vocoder</b>	Configures vocoders in a preference list (up to 8 preferred vocoders) that will be included with same order in SDP message. Vocoder types are G.711 A-/U-law, G.726-32, G.723, G.729, iLBC and OPUS
<b>Voice Frames per TX</b>	Transmits a specific number of voice frames per packet. Default is <b>2</b> ; increases to 10/20/32/64 for G711/G726/G723/other codecs respectively.
<b>G723 Rate</b>	Operates at specified encoding rate for G.723 vocoder. Available encoding rates are 6.3kbps or 5.3kbps. Default is <b>6.3kbps</b> .
<b>iLBC Frame Size</b>	Specifies iLBC packet frame size (20ms or 30ms). Default is <b>20ms</b> .



<b>Disable OPUS Stereo in SDP</b>	Disables OPUS stereo in SDP. Default is <b>No</b> .
<b>iLBC Payload Type</b>	Determines payload type for iLBC. Valid range is between 96 and 127. Default is <b>97</b> .
<b>OPUS Payload Type</b>	Determines payload type for OPUS. Valid range is between 96 and 127. Default is <b>123</b> .
<b>VAD</b>	Allows detecting the absence of audio and conserves bandwidth by preventing the transmission of "silent packets" over the network. Default is <b>No</b> .
<b>Symmetric RTP</b>	Changes the destination to send RTP packets to the source IP address and port of the inbound RTP packet last received by the device. Default is <b>No</b> .
<b>Fax Mode</b>	Specifies the fax mode: T.38 (Auto Detect) FoIP by default, or Pass-Through. If using Pass-through mode, select preference codec as PCMU or PCMA.
<b>Re-Invite after Fax Tone Detected</b>	Permits the unit to send out the re-INVITE for T.38 or Fax Pass Through if a fax tone is detected. Default is <b>Enabled</b>
<b>Jitter Buffer Type</b>	Selects jitter buffer type (Fixed or Adaptive) based on network conditions.
<b>Jitter Buffer Length</b>	<ul style="list-style-type: none"> <li>• <b>High</b> (initial 200ms, min 40ms, max 600ms) Note: not all vocoders can meet the high requirement.</li> <li>• <b>Medium</b> (initial 100ms, min 20ms, max 200ms).</li> <li>• <b>Low</b> (initial 50ms, min 10ms, max 100ms).</li> </ul>
<b>SRTP Mode</b>	Selects SRTP mode to use ("Disabled", "Enabled but not forced", or "Enabled and forced"). Default is <b>Disabled</b> It uses SDP Security Description to exchange key. Please refer to SDES: <a href="https://tools.ietf.org/html/rfc4568">https://tools.ietf.org/html/rfc4568</a> SRTP: <a href="https://www.ietf.org/rfc/rfc3711.txt">https://www.ietf.org/rfc/rfc3711.txt</a>
<b>Crypto Life Time</b>	Adds crypto life time header to SRTP packets. Default is <b>Yes</b> .
<b>SLIC Setting</b>	Depends on standard phone type (and location).
<b>Caller ID Scheme</b>	Selects the caller id scheme, for example: Bellcore/Telcordia, ETSI-FSK ...
<b>DTMF Caller ID</b>	Defines the start and stop tones (Default, A, B, C, D or #) to delimit CID.
<b>Disable Unknown Caller ID</b>	Disable analog phone's caller ID when receiving a call with "Anonymous", "unavailable" or "unknown" in FROM header and without "Display info".



	<p><b>Note:</b> This relies also on analog phone's design, some phones will still display "unknown" with this feature enabled. Default is <b>No</b>.</p>
<b>Replace Beginning '+' with 00 in Caller ID</b>	<p>When this feature is set to Yes, device will replace the "+" sign at the beginning of a number in the FROM header. Default is <b>No</b>.</p>
<b>Polarity Reversal</b>	<p>Reverses the polarity upon call establishment and termination. Default is <b>No</b>.</p>
<b>Loop Current Disconnect</b>	<p>Allows the traditional PBX used with HT812/HT814 to apply this method for signaling call termination. Method initiates short voltage drop on the line when remote (VoIP) side disconnects an active call. Default is <b>No</b>.</p>
<b>Play busy/reorder tone before Loop Current Disconnect</b>	<p>Allow user to configure if it will play busy/reorder tone before loop current disconnect upon call fail. Default is <b>No</b>.</p>
<b>Loop Current Disconnect Duration</b>	<p>Configures the duration of voltage drop described in topic above. HT812/HT814 support a duration range from 100 to 10000ms. Default value is <b>200</b>.</p>
<b>Enable Pulse Dialing</b>	<p>Allow users to enable Pulse Dialing option under FXS Port. Default is <b>No</b>.</p>
<b>Pulse Dialing Standard</b>	<p>Allows users to use Swedish pulse dialing standard or New Zealand pulse dialing standard. Default is <b>General Standard</b>.</p>
<b>Enable Hook Flash</b>	<p>Enables the FLASH button to be used for terminating calls. Default is <b>Yes</b>.</p>
<b>Hook Flash Timing</b>	<p>Defines the time period when the cradle is pressed (Hook Flash) to simulate FLASH. To prevent unwanted activation of the Flash/Hold and automatic phone ring-back, adjust this time value. HT812/HT814 support a range from 40 to 2000 ms. Default values are <b>300</b> minimum and <b>1100</b> maximum.</p>
<b>On Hook Timing</b>	<p>Specifies the on-hook time for an on-hook event to be validated. HT812/HT814 support a range from 40 to 2000 ms. Default value is <b>400</b>.</p>
<b>Gain</b>	<p>Adjusts the voice path volume.</p> <ul style="list-style-type: none"> <li>• <b>Rx</b> is a gain level for signals transmitted by FXS</li> <li>• <b>Tx</b> is a gain level for signals received by FXS.</li> </ul> <p>Default = 0dB for both parameters. Loudest volume: +6dB Lowest volume: -6dB.</p>

	<p>User can adjust volume of call using the Rx gain level parameter and the Tx gain level parameter located on the FXS port configuration page.</p> <p>If call volume is too low when using the FXS port (i.e.. the ATA is at user site), adjust volume using the Rx gain level parameter under the FXS port configuration page.</p> <p>If voice volume is too low at the other end, user may increase the far end volume using the Tx gain level parameter under the FXS port configuration PAGE.</p>
<b>Disable Line Echo Canceller</b>	<p>Disables the LEC per call base. Recommended for Fax/Data calls. Default is <b>No</b>.</p>
<b>Disable Network Echo Suppressor</b>	<p>Disables the NEC per call base. Recommended for Fax/Data calls. Default is <b>No</b>.</p>
<b>Outgoing Call Duration Limit</b>	<p>Defines the call duration limit for the outgoing calls. Default is <b>0 (No limit)</b>.</p>
<b>Ring Frequency</b>	<p>Customizes ring frequency. Valid options: 20Hz – 25Hz. Default is <b>20Hz</b>.</p>
<b>Enable High Ring Power</b>	<p>Configures a high ringing voltage output for the ATA.</p>
<b>OnHook DC Feed Current</b>	<p>This feature is used to adjust DC feed current.</p>
<b>RFC2833 Events Count</b>	<p>This feature allows users to customize the count of RFC2833 events. Default is <b>8</b>.</p>
<b>RFC2833 End Events Count</b>	<p>This feature allows users to customize the count of RFC2833 end events. Default is <b>3</b>.</p>
<b>Distinctive Ring Tone</b>	<p>Customizes the Ring Tone 1 to 3 with associate caller ID: when selected, if caller ID is configured, then the device will <b>ONLY</b> use this ring tone when the incoming call is from the Caller ID. System Ring Tone is used for all other calls. When selected but no Caller ID is configured, the selected ring tone will be used for all incoming calls using the FXS port. Distinctive ring tones can be configured not only for matching a whole number, but also for matching prefixes. In this case the symbol “x+” will be used.</p> <p><b>For example:</b> if configured as 617x+, Ring Tone 1 will be used in case of call arrived from the area code 617. Any other incoming call will ring using cadence defined in parameter System Ring Cadence located under Advanced Settings Configuration page.</p> <p><b>Note:</b> If server supports Alert-Info header and standard ring tone set (Bellcore) or distinctive ring tone 1-10 is specified, then the ring tone in the</p>

	<p>Alert-Info header from server will be used. Bellcore rings and tones are independent from custom ring tones.</p> <p>The custom ring tones can also be specified by alert-info header, for example <i>Alert-Info: ;info=ring5</i></p>
<b>Ring tones</b>	<p>Configures the ring tone cadence preferences. User has 10 choices.</p> <p>The configuration, completed in Distinctive Ring Tones block in the same page, applies to ring tones cadences configured here.</p>
<b>Distinctive Call Waiting Tone</b>	<p>Customizes the Call Waiting Tone 1 to 10 with associate caller ID: when selected, if caller ID is configured, then the device will ONLY use this call waiting tone when the incoming call waiting is from the Caller ID. When selected but no Caller ID is configured, the selected call waiting tone will be used for all incoming waiting calls using the FXS port. Distinctive Call Waiting Tones can be configured not only for matching a whole number, but also for matching prefixes. In this case symbol “x+” will be used.</p> <p><b>For example:</b> If configured as 617x+, Call Waiting Tone 1 will be used in case of waiting call arrived from the area code 617. Any other incoming call waiting will be using cadence defined in parameter Call Waiting Tone located under Advanced Settings Configuration page.</p>
<b>Call Waiting Tones</b>	<p>This feature allows user to customize call waiting tone. User has 10 choices.</p> <p><i>Syntax: f1=val[,f2=val[,c=on1/off1[-on2/off2[-on3/off3]]]];</i></p> <p>(Frequencies are in (300, 3400) Hz and cadence on and off are in (0, 64000) ms)</p> <p>Note: The configuration, completed in Distinctive Call Waiting Tones block in the same page, applies to call waiting cadences configured here.</p> <p>Default is <b>f1=440@-13,c=300/10000;</b></p>
<b>Call Features Settings</b>	
<b>Enable Call Features</b>	<p>When enabled, Do Not Disturb, Call Forward and other call features can be used via the local feature codes on the phone. Otherwise, the ITSP feature codes will be used. Enable All will override all individual features enable setting. Default is <b>Yes</b></p>
<b>Reset Call Features</b>	<p>Allows users to reset all call features configuration.</p> <p>Default is <b>No</b></p>
<b>SRTP Feature</b>	<p>Allow users to customize the SRTP feature codes. Default is <b>Yes</b></p> <ul style="list-style-type: none"> <li>- Enable SRTP: Default is <b>16</b></li> <li>- Disable SRTP: Default is <b>17</b></li> </ul>





<b>SRTP per call Feature</b>	<ul style="list-style-type: none"> <li>- Enable SRTP per call: Default is <b>18</b></li> <li>- Disable SRTP per call: Default is <b>19</b></li> </ul>
<b>CID Feature</b>	<p>Allow users to customize the CID feature codes. Default is <b>Yes</b></p> <ul style="list-style-type: none"> <li>- Enable CID: Default is <b>31</b></li> <li>- Disable CID: Default is <b>30</b></li> </ul>
<b>CID per call Feature</b>	<ul style="list-style-type: none"> <li>- Enable CID per call: Default is <b>82</b></li> <li>- Disable CID per call: Default is <b>67</b></li> </ul>
<b>Direct IP Calling Feature</b>	<p>Allow users to customize the Direct IP feature code. Default is <b>Yes</b></p> <ul style="list-style-type: none"> <li>- Direct IP Calling: Default is <b>47</b></li> </ul>
<b>CW Feature</b>	<p>Allow users to customize the CW feature codes. Default is <b>Yes</b></p> <ul style="list-style-type: none"> <li>- Enable CW: Default is <b>51</b></li> <li>- Disable CW: Default is <b>50</b></li> </ul>
<b>CW per call Feature</b>	<ul style="list-style-type: none"> <li>- Enable CW per call: Default is <b>71</b></li> <li>- Disable CW per call: Default is <b>70</b></li> </ul>
<b>Call Return Feature</b>	<p>Allow users to customize the Call Return feature code. Default is <b>Yes</b></p> <ul style="list-style-type: none"> <li>- Call return: Default is <b>69</b></li> </ul>
<b>Unconditional Forward Feature</b>	<p>Allow users to customize the Unconditional Forward feature codes. Default is <b>Yes</b></p> <ul style="list-style-type: none"> <li>- Enable Unconditional Forward: Default is <b>72</b></li> <li>- Disable Unconditional Forward: Default is <b>73</b></li> </ul>
<b>Busy Forward Feature</b>	<p>Allow users to customize the Busy Forward feature codes. Default is <b>Yes</b></p> <ul style="list-style-type: none"> <li>- Enable Busy Forward: Default is <b>90</b></li> <li>- Disable Busy Forward: Default is <b>91</b></li> </ul>
<b>Delayed Forward Feature</b>	<p>Allow users to customize the Delayed Forward feature codes. Default is <b>Yes</b></p> <ul style="list-style-type: none"> <li>- Enable Delayed Forward: Default is <b>92</b></li> <li>- Disable Delayed Forward: Default is <b>93</b></li> </ul>
<b>Paging Feature</b>	<p>Allow users to customize the Paging feature code. Default is <b>Yes</b></p> <ul style="list-style-type: none"> <li>- Paging: Default is <b>74</b></li> </ul>
<b>DND Feature</b>	<p>Allow users to customize the CW feature codes. Default is <b>Yes</b></p> <ul style="list-style-type: none"> <li>- Enable DND: Default is <b>78</b></li> <li>- Disable DND: Default is <b>79</b></li> </ul>
<b>Blind Transfer Feature</b>	<p>Allow users to customize the Blind Transfer feature code. Default is <b>Yes</b></p> <ul style="list-style-type: none"> <li>- Enable Blind Transfer: Default is <b>87</b></li> </ul>

<b>Disable LEC per call Feature</b>	Default is <b>Yes</b> - Disable LEC per call: Default is <b>03</b>
<b>Disable Bellcore Style 3-Way Conference</b>	Default is <b>No</b>
<b>Star Code 3WC Feature</b>	Default is <b>Yes</b> - Star Code 3WC: Default is <b>23</b>
<b>Forced Codec Feature</b>	Allow users to customize the Forced Codec feature code. Default is <b>Yes</b> - Forced Codec: Default is <b>02</b>
<b>PCMU Codec Feature</b>	Default is <b>Yes</b> - PCMU Codec: Default is <b>7110</b>
<b>PCMA Codec Feature</b>	Default is <b>Yes</b> - PCMA Codec: Default is <b>7111</b>
<b>G723 Codec Feature</b>	Default is <b>Yes</b> - G723 Codec: Default is <b>723</b>
<b>G729 Codec Feature</b>	Default is <b>Yes</b> - G729 Codec: Default is <b>729</b>
<b>iLBC Codec Feature</b>	Default is <b>Yes</b> - iLBC Codec: Default is <b>7201</b>

## FXS Ports Page Definitions

Table 10: FXS Ports

FXS Ports	
<b>Port</b>	Display the port number
<b>SIP User ID</b>	Defines user account information provided by VoIP service provider (ITSP). Usually in the form of digit similar to phone number or actually a phone number.
<b>Authenticate ID</b>	Determines account authenticate ID provided by VoIP service provider (ITSP). Can be identical to or different from "SIP user ID".
<b>Password</b>	Specifies account password provided by VoIP service provider (ITSP) to register to SIP servers.



<b>Name</b>	Chooses a name to be associated to user.
<b>Profile ID</b>	Defines the profile ID for each port.
<b>Hunting Group</b>	<p>Configures hunting group feature on the specific port.</p> <p>For example: Port 1, 2, and 3 are members of the same Hunting Group. Port 1 is registered with a SIP account.</p> <p>Ports 2, and 3 are not registered. Ports 2 and 3 will be able to place outbound calls using the SIP account of port 1. Select appropriate value for Hunting Group feature.</p> <p>The original SIP account should be set to Active while the group members should be set to the port number of the Active Port.</p> <p><u>Example configuration of a Hunting group:</u></p> <p>FXS Port #1: SIP UserID and Authenticate ID entered, Hunting group set to "Active"</p> <p>FXS Port #2: SIP UserID and Authenticate ID left blank, Hunting Group set to "1"</p> <p>FXS Port #3: SIP UserID and Authenticate ID left blank, Hunting Group set to "1"</p> <p>FXS Port #4: SIP UserID and Authenticate ID entered, Hunting group set to "None"</p> <p>Hunting Group 1 contains ports 1, 2, 3. FXS port 4 is registered but it is not added to the Hunting Group 1.</p> <p><b>Note:</b> HT812/HT814 will use CID name from FXS port initiating the outgoing call if the "Name" field is entered for that specific port.</p>
<b>Request URI Routing ID</b>	If configured, device will route the incoming call to designated port by request URI user ID in SIP INVITE.
<b>Enable Port</b>	Enables / Disables the port.
<b>Off hook Auto-Dial</b>	Configures a User ID or extension number that is automatically dialed when off-hook. Only the user part of a SIP address needs is entered here. The HT812/HT814 will automatically append the "@" and the host portion of the corresponding SIP address.



## Important Settings

### NAT Settings

If you plan to keep the Handy Tone within a private network behind a firewall, we recommend using STUN Server.

The following three settings are useful in the STUN Server scenario:

1. STUN Server (under advanced settings webpage) enter a STUN server IP (or FQDN) that you may have or look up a free public STUN server on the internet and enter it on this field. If using public IP, keep this field blank.
2. Use random SIP/RTP ports (under advanced settings webpage), this setting depends on your network settings. Generally, if you have multiple IP devices under the same network, it should be set to Yes. If using a public IP address, set this parameter to No.
3. NAT traversal (under the FXS web page) Set this to Yes when gateway is behind firewall on a private network.

### DTMF Methods

The HT812/HT814 support the following DTMF mode:

- DTMF in-audio
- DTMF via RTP (RFC2833)
- DTMF via SIP INFO

Set priority of DTMF methods according to your preference. This setting should be based on your server DTMF setting.

### Preferred Vocoder (Codec)

The HT812/HT814 support following voice codecs. On Profile pages, choose the order of your codecs:

- PCMU/A (or G711 $\mu$ /a)
- G729 A/B
- G723.1
- G726
- iLBC
- OPUS
- G722



## Configuring HT812/HT814 Through Voice Prompts

As mentioned previously, The HT812/HT814 have a built-in voice prompt menu for simple device configuration. Please refer to "[Understanding HT812/HT814 Interactive Voice Prompt Response Menu](#)" for more information about IVR and how to access its menu.

- **DHCP MODE**

Select voice menu option 01 to enable HT812/HT814 to use DHCP.

- **STATIC IP MODE**

Select voice menu option 01 to enable HT812/HT814 to use STATIC IP mode, then use option 02, 03, 04, 05 to set up IP address, Subnet Mask, Gateway, and DNS server respectively.

- **PPPOE MODE**

Select voice menu option 01 to allow the HT812/HT814 to enable the PPPoE mode. PPPoE Username and Password should be configured from web GUI.

- **FIRMWARE SERVER IP ADDRESS**

Select voice menu option 13 to configure the IP address of the firmware server.

- **CONFIGURATION SERVER IP ADDRESS**

Select voice menu option 14 to configure the IP address of the configuration server.

- **UPGRADE PROTOCOL**

Select the menu option 15 to choose firmware and configuration upgrade protocol between TFTP, FTP, FTPS, HTTP and HTTPS. Default is HTTPS.

- **FIRMWARE UPGRADE MODE**

Select voice menu option 17 to choose firmware upgrade mode among the following three options:

1) Always check, 2) check when pre/suffix changes, and 3) never upgrade.

- **WAN PORT WEB ACCESS**

Select voice menu option 12 to enable/disable web access from WAN port. Press 9 in this menu to toggle between enable / disable. Default is disabled.

## Configuration through a Central Server

The HT812/HT814 can be automatically configured from a central provisioning system.

When HT812/HT814 boots up, it will send TFTP, FTP/FTPS or HTTP/HTTPS requests to download configuration files, "cfg000b82xxxxx" and "cfg00082xxxxx.xml", where "000b82xxxxx" is the LAN MAC address of the HT812/HT814. If the download of "cfgxxxxxxxxxxxx.xml" is not successful, the provision program will issue request a generic configuration file "cfg.xml". Configuration file name should be in lower case letters. The configuration data can be downloaded via TFTP, FTP/FTPS or HTTP/HTTPS from the central server. A service provider or an enterprise with large deployment of HT812/HT814 can easily



manage the configuration and service provisioning of individual devices remotely from a central server.

Grandstream provides a central provisioning system GAPS (Grandstream Automated Provisioning System) to support automated configuration of Grandstream devices. GAPS uses HTTPS and other communication protocols to communicate with each individual Grandstream device for firmware upgrade, remote reboot, etc. Grandstream provides GAPS service to VoIP service providers. Use GAPS for either simple redirection or with certain special provisioning settings. At boot-up, Grandstream devices by default point to Grandstream provisioning server GAPS, based on the unique MAC address of each device, GAPS provision the devices with redirection settings so that they will be redirected to customer's TFTP or HTTP/HTTPS/FTP/FTPS server for further provisioning. Grandstream also provides configuration tools (Windows and Linux/Unix version) to facilitate the task of generating device configuration files.

The Grandstream configuration tools are free to end users. The configuration tools and configuration templates are available for download from <https://www.grandstream.com/support/tools>

## Register a SIP Account

The HT812/HT814 support 2 profiles which can be configured with 2 SIP accounts. Please refer to the following steps in order to register your accounts via web user interface


1. Access your HT812/HT814 web UI by entering its IP address in your favorite browser.
2. Enter your admin password (default: admin).
3. Press **Login** to access your settings.
4. Go to **Profile (1 or 2)** pages.
5. In **Profile** tab, set the following:
  - a. **Account Active** to **Yes**.
  - b. **Primary SIP Server** field with your SIP server IP address or FQDN.
  - c. **Failover SIP Server** with your Failover SIP Server IP address or FQDN. Leave empty if not available.
  - d. **Prefer Primary SIP Server** to **No** or **Yes** depending on your configuration. Set to **No** if no Failover SIP Server is defined. If "**Yes**", account will register to Primary SIP Server when failover registration expires.
  - e. **Outbound Proxy**: Set your Outbound Proxy IP Address or FQDN. Leave empty if not available.
6. After configuring the SIP server and activating the profiles, you should access to **FXS Ports** page to register your accounts. In **FXS Ports** tab, set the following:
  - a. **SIP User ID**: User account information, provided by VoIP service provider (ITSP). Usually in the form of digit similar to phone number or actually a phone number.



- b. **Authenticate ID:** SIP service subscriber's Authenticate ID used for authentication. Can be identical to or different from SIP User ID.
- c. **Authenticate Password:** SIP service subscriber's account password to register to SIP server of ITSP. For security reasons, the password will field will be shown as empty.
- d. **Name:** Any name to identify this specific user.
- e. Set **Enable Port** to **Yes**.

For more information, related to above options please refer to [Profile\(s\) settings](#) and [FXS Port Settings](#).

- 7. Press **Apply** at the bottom of the page to save your configuration.



**Grandstream Device Configuration**

STATUS BASIC SETTINGS ADVANCED SETTINGS **PROFILE 1** PROFILE 2 FXS PORTS

**Profile Active:**  No  Yes


**Primary SIP Server:**  (e.g., sip.mycompany.com, or IP address)

**Failover SIP Server:**  (Optional, used when primary server no response)

**Prefer Primary SIP Server:**  No  Yes (yes - will register to Primary Server if Failover registration expires)

**Outbound Proxy:**  (e.g., proxy.myprovider.com, or IP address, if any)

Figure 11: SIP Profiles Settings



**Grandstream Device Configuration**

STATUS BASIC SETTINGS ADVANCED SETTINGS PROFILE 1 PROFILE 2 **FXS PORTS**

User Settings

Port	SIP User ID	Authenticate ID	Password	Name	Profile ID	Hunting Group	Request URI	Routing ID	Enable Port
1	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	Profile 1 ▼	None ▼	<input type="text"/>	<input type="text"/>	<input type="radio"/> No <input checked="" type="radio"/> Yes
2	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	Profile 1 ▼	None ▼	<input type="text"/>	<input type="text"/>	<input type="radio"/> No <input checked="" type="radio"/> Yes
3	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	Profile 1 ▼	None ▼	<input type="text"/>	<input type="text"/>	<input type="radio"/> No <input checked="" type="radio"/> Yes
4	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	Profile 1 ▼	None ▼	<input type="text"/>	<input type="text"/>	<input type="radio"/> No <input checked="" type="radio"/> Yes

Port Offhook Auto-dial

1

2

3

4

Update **Apply** Cancel Reboot

All Rights Reserved Grandstream Networks, Inc. 2006-2017

Figure 12: SIP Accounts settings

After applying your configuration, your account will register to your SIP Server, you can verify if it has been correctly registered with your SIP server from your HT812/HT814 web interface under **Status → Port Status → Registration** (If it displays **Registered**, it means that your account is fully registered, otherwise it will display **Not Registered** so in this case you must double check the settings or contact your provider).

Grandstream Device Configuration																							
STATUS	BASIC SETTINGS	ADVANCED SETTINGS	PROFILE 1 PROFILE 2 FXS PORTS																				
MAC Address:	00:0B:82:A3:38:FD																						
WAN IPv4 Address:	192.168.5.163																						
WAN IPv6 Address:																							
Product Model:	HT814																						
Serial Number:																							
Hardware Version:	V1.6A Part Number -- 9610004916A																						
Software Version:	Program -- 1.0.13.7 Bootloader -- 1.0.13.1 Core -- 1.0.13.1 Base -- 1.0.13.7 CPE -- 0.19.7.10																						
Software Status:	Running Mem: 22840																						
System Up Time:	11:39:53 up 3 min																						
CPU Load:	0%																						
Network Cable Status:	WAN -- Up 100Mbps Full LAN -- Down 10Mbps Half																						
PPPoE Link Up:	Disabled																						
NAT:	Unknown NAT																						
Port Status:	<table border="1"> <thead> <tr> <th>Port</th> <th>Hook</th> <th>User ID</th> <th>Registration</th> </tr> </thead> <tbody> <tr> <td>FXS 1</td> <td>On Hook</td> <td>1001</td> <td>Registered</td> </tr> <tr> <td>FXS 2</td> <td>On Hook</td> <td></td> <td>Not Registered</td> </tr> <tr> <td>FXS 3</td> <td>On Hook</td> <td></td> <td>Not Registered</td> </tr> <tr> <td>FXS 4</td> <td>On Hook</td> <td></td> <td>Not Registered</td> </tr> </tbody> </table>			Port	Hook	User ID	Registration	FXS 1	On Hook	1001	Registered	FXS 2	On Hook		Not Registered	FXS 3	On Hook		Not Registered	FXS 4	On Hook		Not Registered
Port	Hook	User ID	Registration																				
FXS 1	On Hook	1001	Registered																				
FXS 2	On Hook		Not Registered																				
FXS 3	On Hook		Not Registered																				
FXS 4	On Hook		Not Registered																				

Figure 13: Accounts Status

**Note:** When all the FXS ports are registered, the simultaneous rings will have one second delay between each ring on each phone.

## Call Features

The HT812/HT814 support all the traditional and advanced telephony features.

Table 11: HT812/HT814 Call Features

Key	Call features
*02	<b>Forcing a Codec</b> (per call) *027110 (PCMU), *027111 (PCMA), *02723 (G723), *02729 (G729), *027201 (iLBC), *02722 (G722).
*03	<b>Disable LEC</b> (per call) Dial “*03” +” number”. No dial tone is played in the middle.
*16	<b>Enable SRTP</b>
*17	<b>Disable SRTP</b>
*30	<b>Block Caller ID</b> (for all subsequent calls)
*31	<b>Send Caller ID</b> (for all subsequent calls)
*47	<b>Direct IP Calling</b> . Dial “*47” + “IP address”. No dial tone is played in the middle.





<b>*50</b>	<b>Disable Call Waiting</b> (for all subsequent calls)
<b>*51</b>	<b>Enable Call Waiting</b> (for all subsequent calls)
<b>*67</b>	<b>Block Caller ID (per call)</b> . Dial “*67” +” number”. <b>No</b> dial tone is played in the middle.
<b>*82</b>	<b>Send Caller ID (per call)</b> . Dial “*82” +” number”. <b>No</b> dial tone is played in the middle.
<b>*69</b>	<b>Call Return Service</b> : Dial *69 and the phone will dial the last incoming phone number received.
<b>*70</b>	<b>Disable Call Waiting (per call)</b> . Dial “*70” +” number”. <b>No</b> dial tone is played in the middle.
<b>*71</b>	<b>Enable Call Waiting (per call)</b> . Dial “*71” +” number”. <b>No</b> dial tone is played in the middle
<b>*72</b>	<b>Unconditional Call Forward</b> : Dial “*72” and then the forwarding number followed by “#”. Wait for dial tone and hang up. (dial tone indicates successful forward)
<b>*73</b>	<b>Cancel Unconditional Call Forward</b> . To cancel “Unconditional Call Forward”, dial “*73”, wait for dial tone, then hang up.
<b>*74</b>	<b>Enable Paging Call</b> : Dial “*74” and then the destination phone number you want to page.
<b>*78</b>	<b>Enable Do Not Disturb (DND)</b> : When enabled all incoming calls are rejected.
<b>*79</b>	<b>Disable Do Not Disturb (DND)</b> : When disabled, incoming calls are accepted.
<b>*87</b>	<b>Blind Transfer</b>
<b>*90</b>	<b>Busy Call Forward</b> : Dial “*90” and then the forwarding number followed by “#”. Wait for dial tone then hang up.
<b>*91</b>	<b>Cancel Busy Call Forward</b> . To cancel “Busy Call Forward”, dial “*91”, wait for dial tone, then hang up.
<b>*92</b>	<b>Delayed Call Forward</b> . Dial “*92” and then the forwarding number followed by “#”. Wait for dial tone then hang up.
<b>*93</b>	<b>Cancel Delayed Call Forward</b> . To cancel Delayed Call Forward, dial “*93”, wait for dial tone, then hang up
<b>Flash/ Hook</b>	Toggles between active call and incoming call (call waiting tone). If not in conversation, flash/hook will switch to a new channel for a new call.
<b>#</b>	Pressing pound sign will serve as Re-Dial key.

## Rebooting HT812/HT814 from Remote

Press “Reboot” button at the bottom of the configuration menu to reboot the ATA remotely. The web browser will then display a message window to confirm that reboot is underway. Wait 30 seconds to log in again.



## UPGRADING AND PROVISIONING

The HT812/HT814 can be upgraded via TFTP/FTP/FTPS/HTTP/HTTPS by configuring the URL/IP Address for the TFTP/FTP/FTPS/HTTP/HTTPS server and selecting a download method. Configure a valid URL for TFTP or FTP/FTPS or HTTP/HTTPS (default is HTTPS); the server name can be FQDN or IP address.

### Examples of valid URLs:


firmware.grandstream.com

fw.ipvideotalk.com/gs

### Firmware Upgrade procedure

Please follow below steps in order to upgrade the firmware version of your HT812/HT814:

1. Access your HT812/HT814 UI by entering its IP address in your favorite browser.
2. Enter your admin password (default: admin).
3. Press **Login** to access your settings.
4. Go to **Advanced Settings** → **Firmware Upgrade and Provisioning** page, and enter the IP address or the FQDN for the upgrade server in "**Firmware Server Path**" field and choose to upgrade via **TFTP** or **HTTP/HTTPS** or **FTP/FTPS**.
5. Make sure to check "**Always Check for New Firmware**".
6. Update the change by clicking the "**Apply**" button at the bottom of the page. Then "**Reboot**" or power cycle the HT812/HT814 to update the new firmware.



*Firmware Upgrade and Provisioning:* Upgrade Via  TFTP  HTTP  HTTPS  FTP  FTPS

Firmware Server Path:

Config Server Path:

XML Config File Password:

HTTP/HTTPS/FTP/FTPS User Name:

HTTP/HTTPS/FTP/FTPS Password:

Firmware File Prefix:  Firmware File Postfix:

Config File Prefix:  Config File Postfix:

Allow DHCP Option 66 or 160 to override server:  
 No  Yes

3CX Auto Provision:  
 No  Yes

Automatic Upgrade:  
 No  
 Yes, every  minutes(30-5256000).  
 Yes, daily at start hour  (0-23), at end hour  (0-23).  
 Yes, weekly on day  (0-6).

Randomized Automatic Upgrade:  No  Yes

Always Check for New Firmware at Boot up  
 Check New Firmware only when F/W pre/suffix changes  
 Always Skip the Firmware Check

Figure 14: Firmware Upgrade Page

## Upgrading via Local Directory

1. Download the firmware file from Grandstream web site
2. Unzip it and copy the file in to a folder in your PC
3. From the HT812/HT814 web interface (Advanced Settings page) you can browse your hard drive and select the folder you previously saved the file (HT8xfw.bin)
4. Click "Upload Firmware" and wait few minutes until the new program is loaded.

**Note:** Always check the status page to see that the program version has changed.

## Upgrading via Local TFTP/HTTP/HTTPS/FTP/FTPS Servers

For users that would like to use remote upgrading without a local TFTP/FTP/FTPS/HTTP/HTTPS server, Grandstream offers a NAT-friendly HTTP server. This enables users to download the latest software upgrades for their devices via this server. Please refer to the webpage:

<https://www.grandstream.com/support/firmware>

Alternatively, users can download for example a free TFTP or HTTP server and conduct a local firmware upgrade. A free window version TFTP server is available for download from:

[http://www.solarwinds.com/products/freetools/free\\_tftp\\_server.aspx](http://www.solarwinds.com/products/freetools/free_tftp_server.aspx)

<http://tftpd32.jounin.net/>.

Instructions for local firmware upgrade via TFTP:

1. Unzip the firmware files and put all of them in the root directory of the TFTP server.
2. Connect the PC running the TFTP server and the phone to the same LAN segment.
3. Launch the TFTP server and go to the File menu->Configure->Security to change the TFTP server's default setting from "**Receive Only**" to "**Transmit Only**" for the firmware upgrade.
4. Start the TFTP server and configure the TFTP server in the phone's web configuration interface.
5. Configure the Firmware Server Path to the IP address of the PC.
6. Save and Apply the changes and reboot the HT812/HT814.

End users can also choose to download a free HTTP server from <http://httpd.apache.org/> or use Microsoft IIS web server.

## Firmware and Configuration File Prefix and Postfix

Firmware Prefix and Postfix allows device to download the firmware name with the matching Prefix and Postfix. This makes it the possible to store all of the firmware with different version in one single directory. Similarly, Config File Prefix and Postfix allows device to download the configuration file with the matching Prefix and Postfix. Thus, multiple configuration files for the same device can be stored in one directory. In addition, when the field "Check New Firmware only when F/W pre/suffix changes" is set to "Yes", the device will only issue firmware upgrade request if there are changes in the firmware Prefix or Postfix.



## Managing Firmware and Configuration File Download

When “Automatic Upgrade” is set “**Yes, every**” the auto check will be done in the minute specified in this field. If set to “**daily at hour (0-23)**”, Service Provider can use P193 (Auto Check Interval) to have the devices do a daily check at the hour set in this field with either Firmware Server or Config Server. If set to “**weekly on day (0-6)**” the auto check will be done on the day specified in this field. This allows the device to periodically check if there are any new changes need to be taken on a scheduled time. By defining different intervals in P193 for different devices, Server Provider can spread the Firmware or Configuration File download in minutes to reduce the Firmware or Provisioning Server load at any given time

### Configuration File Download

Grandstream SIP Devices can be configured via the Web Interface as well as via a Configuration File (binary or XML) through TFTP, FTP/FTPS or HTTP/HTTPS. The **Config Server Path** is the TFTP or HTTP/HTTPS server path for the configuration file. It needs to be set to a valid URL, either in FQDN or IP address format. The **Config Server Path** can be the same or different from the **Firmware Server Path**. A configuration parameter is associated with each particular field in the web configuration page. A parameter consists of a Capital letter P and 2 to 3 (Could be extended to 4 in the future) digit numeric numbers. i.e., P2 is associated with the "New Password" in the Web GUI->Maintenance->Web/SSH Access page->Admin Password. For a detailed parameter list, please refer to the corresponding firmware release configuration template.

When the HT812/HT814 boots up or reboots, it will send a request to download a file named "cfgxxxxxxxxxxx" followed by a configuration XML file named "cfgxxxxxxxxxxx.xml", where "xxxxxxxxxxx" is the MAC address of the phone, i.e., "cfg000b820102ab" and "cfg000b820102ab.xml". If the download of "cfgxxxxxxxxxxx.xml" file is not successful, the provision program will download a generic cfg.xml file and then download cfg<Model>.xml. The configuration file name should be in lower case letters.

HT818/HT814 supports DHCP option 67 allowing to provide custom name for the provisioning file. If DHCP option 67 is used, the following file download sequence will be applied:

Step 1: cfg<MAC>

Step 2: <option 67 bootfile> → cfg<MAC>.xml → cfg.xml → cfg<Model>.xml

#### Notes:

1. Only XML or binary config file formats are accepted.
2. The MAC header in XML config file should be the device MAC or needs to be removed completely.



```
<?xml version="1.0" encoding="UTF-8"?>
<!-- HT812 XML Provisioning Configuration -->
<gs_provision version="1">
  <mac>000B82B04B4E</mac>
  - <config version="2">
    <P855>0</P855>
    <P28107>0</P28107>
    <P730>0</P730>
    <P694>97</P694>
```

Figure 15: XML Config File - MAC Header

For more details on XML provisioning, please refer to:

[https://www.grandstream.com/sites/default/files/Resources/gs\\_provisioning\\_guide.pdf](https://www.grandstream.com/sites/default/files/Resources/gs_provisioning_guide.pdf)

## RESTORE FACTORY DEFAULT SETTINGS



Restoring the Factory Default Settings will delete all configuration information on the phone. Please backup or print all the settings before you restore to the factory default settings. Grandstream is not responsible for restoring lost parameters and cannot connect your device to your VoIP service provider.

There are three (3) methods for resetting your unit:

### Using the Reset Button

To reset default factory settings using the reset button please follow the steps above:

1. Unplug the Ethernet cable.
2. Locate the reset hole on the back panel of your HT812/HT814.
3. Insert a pin in this hole, and press for about 7 seconds.
4. Take out the pin. All unit settings are restored to factory settings

### Using the IVR Command

Reset default factory settings using the IVR prompt:

1. Dial “\*\*\*\*” for voice prompt.
2. Enter “99” and wait for “reset” voice prompt.
3. Enter the encoded MAC address (Look below on how to encode MAC address).
4. Wait 15 seconds and device will automatically reboot and restore factory settings.

### Encode the MAC Address

1. Locate the MAC address of the device. It is the 12-digit HEX number on the bottom of the unit.
2. Key in the MAC address. Use the following mapping:

Table 12: MAC Address Key Mapping

Key	Mapping
0-9	0-9
A	22 (press the “2” key twice, “A” will show on the LCD)
B	222



<b>C</b>	2222
<b>D</b>	33 (press the “3” key twice, “D” will show on the LCD)
<b>E</b>	333
<b>F</b>	3333

For example: if the MAC address is 000b8200e395, it should be keyed in as “0002228200333395”

## Reset from Web Interface (Reset Type)

1. Access your HT812/HT814 UI by entering its IP address in your favorite browser.
2. Enter your admin password (default: admin).
3. Press **Login** to access your settings.
4. Go to **Basic Settings** → **Reset Type**
5. Press **Reset** button (after selecting the reset type).

- **Full Reset:** This will make a full reset
- **ISP Data:** This will reset only the basic settings, like IP mode, PPPoE and Web port
- **VoIP Data Reset:** This will reset only the data related with a service provider like SIP server, sip user ID, provisioning, and others.

### Notes:

- Factory Reset will be disabled if the “Lock keypad update” is set to “Yes”.
- If the HT812/HT814 were previously locked by your local service provider, pressing the RESET button will only restart the unit. The device will not return to factory default settings.

## Reset using SIP NOTIFY

1. Access your HT812/HT814 UI by entering its IP address in your favorite browser.
2. Go to **Profile #** page.
3. Set “Allow SIP Factory Reset” to “Yes”. (Default is No)
4. Once a SIP NOTIFY with “event: reset” is received, the ATA will perform factory reset.

**Note:** Received SIP NOTIFY will be first challenged for authentication purpose before taking factory reset action. The authentication can be done either using admin credentials (if no SIP account is configured) or using SIP account credentials.



## EXPERIENCING HT812/HT814

Please visit our website: <https://www.grandstream.com> to receive the most up- to-date updates on firmware releases, additional features, FAQs, documentation, and news on new products.

We encourage you to browse our [product related documentation](#), [FAQs](#) and [User and Developer Forum](#) for answers to your general questions. If you have purchased our products through a Grandstream Certified Partner or Reseller, please contact them directly for immediate support.

Our technical support staff is trained and ready to answer all of your questions. Contact a technical support member or [submit a trouble ticket online](#) to receive in-depth support.

Thank you again for purchasing Grandstream analogue telephone adapter, it will be sure to bring convenience to both your business and personal life.

